

VIP-254 series Firmware Upgrade methods:

Please find the firmware of VIP-254, and be sure to check the firmware upgrade steps to load the firmware into machine properly for evaluations.

- a) Log in VIP-254 via Microsoft Internet explorer web browser, and insert <http://VIP-254 IP address/update.htm> in the address bar.
- b) Select update "All ROM", and browse to the firmware location.
- c) Please find the firmware (decompress and find the *.rom file for upgrade)
- d) After firmware loaded, the unit will be reboot, and loaded with factory default values.
- e) Default IP address of the customized firmware: <http://192.168.0.1>; login name/password: [root/null\(no password\)](#)