

## PCI Express 10 Gigabit Ethernet Adapter

Quick Installation Guide

Version 2.0

Thank you for purchasing PLANET ENW-9801 PCI Express 10 Gigabit Ethernet adapter. It supports x4, x8, x16 PCI Express interfaces. The 10 Gigabit Ethernet adapter provides a highly cost-effective solution to upgrading to the 10 Gigabit network with your existing Ethernet infrastructures.


### Operation System Support:

- Windows Server 2008R2 64bits
- Windows Server 2012 64bits
- Windows 7 32 / 64bits
- Windows 8 32 / 64bits
- Linux (2.6x to 3.8.0)

- 1 -

## Hardware Installation

**Step 1:** Please turn off your PC.



**Step 2:** Remove any metal decorations from your hands and wrists.

**Step 3:** Remove the cover from your PC.


**Step 4:** Locate an empty PCI Express slot and remove the corresponding back plate. Save the screw for use in Step 6.

- 3 -

## Installation on Windows 7


**Note** This operation is under Win7 which it is similar to Windows Server 2008.

1. After installing the ENW-9801 to your PC and booting it up, Windows 7 will detect it and you have to install driver.




- 5 -

3. Please select **"Browse my computer for driver software"** for the next step.



4. Insert the bundled CD into the CD-ROM driver.



- 7 -

## Package Contents

ENW-9801 x 1



Low Profile Bracket x 1



Quick Installation Guide x 1




User's Manual CD x 1



- 2 -

**Step 5:** Carefully insert the 10 Gigabit Ethernet Adapter into the chosen slot and press firmly with proper push to ensure it is fully seated in the slot.




**Step 6:** Secure the 10 Gigabit Ethernet Adapter with the screw you saved in Step 4.

**Step 7:** Replace the PC cover.

**Step 8:** Power on your PC and refer to the next section to install driver.


- 4 -

2. Please move and right-click the mouse button for Ethernet Controller item and select **"Update Driver Software"**.




- 6 -

5. Please click **"Browse"** to specify the driver location to install. (Assume **"E"** is your CD-ROM drive, the driver can be found in E:\DR-ENW-9801v2 Driver). Click **"Next"** to continue.




The driver is being installed.




- 8 -

6. During the driver installation, it will pop up one Windows Security message. Please Click **“Install this driver software anyway”** button to continue installation.




- 9 -

For more details, please refer to the manual of our bundled CD-ROM.




- 11 -

7. Click **“Close”** button to complete the driver installation.



- 10 -



- 12 -

# Network Adapter

ENW-9801

[www.PLANET.com.tw](http://www.PLANET.com.tw)

## PCI Express 10G Ethernet Adapter

