## VERIFY THE CONTENTS INSIDE PACKAGE BOX

The package should contain the following items plus ADE-3400. If any item is missing or damaged, please contact the seller immediately

| Quick Installation Guide | CD-ROM | Splitter | Ethernet Cable | Phone Cable | Power Adapter |

STEP 1 : Connect telephone line to the LINE port via splitter

Telephone Line

Telephone

PHONE

MODEM

Splitter

Phone Jack

LINE

Telephone Line

ON/OFF   Power   Ethernet   Line

STEP 2 : Connect network devices to LAN port

Telephone Line

Telephone

PHONE

MODEM

Splitter

Phone Jack

LINE

Telephone Line

ON/OFF   Power   Ethernet   Line

Ethernet Cable

PC
(DHCP Client or Fixed 192.168.1.2)

STEP 3 : Connect the Power and then press the button ⏻.
Check whether the LEDs on the front panel are on accordingly.

Telephone Line

Telephone

PHONE   MODEM

Splitter

LINE

Ethernet
Cable

Phone
Jack

Telephone Line

PC
(DHCP Client or Fixed 192.168.1.2)

Press the button

Power Jack

STEP 4 : Open web browser and type the default IP address (http://192.168.1.1)

User Name: admin
Password: admin

ADSL Router Login

User Name: admin
Password: •••••

Login   Reset

Login

ADSL2/2+ Router ADE-3400

Status   Wizard   Setup   Advanced   Service   Firewall   Maintenance

ADSL Router Status
This page shows the current status and some basic settings of the device.

Device_Info

System

Device_Info   Alias Name   ADE-3400
ADSL   Uptime   0:0:3:21
                  Date/Time   Sun Jan 1 0:3:21 2012
Statistics   Firmware Version   RTK V2.1.1
                  Built Date   Aug 30 2013 14:24:03
                  Serial Number   0330AP81CBT1

DSL

Operational Status   --
Upstream Speed   --
Downstream Speed   --

CWMP Status

Note: Please refer to the User's manual in CD-ROM for more information.

Quick Guide

2011-B50330-003