

# User's Manual

## 60fps Full HD IR IP Camera with Remote Focus and Zoom

► ICA-4210P



---

**Copyright**

Copyright © 2014 by PLANET Technology Corp. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of PLANET.

PLANET makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability or fitness for any particular purpose. Any software described in this manual is sold or licensed "as is". Should the programs prove defective following their purchase, the buyer (and not PLANET, its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software. Further, PLANET reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.

All brand and product names mentioned in this manual are trademarks and/or registered trademarks of their respective holders.

**Federal Communication Commission Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio technician for help.

**FCC Caution**

To assure continued compliance, use only shielded interface cables when connecting to computer or peripheral devices. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Federal Communication Commission (FCC) Radiation Exposure Statement**

This equipment complies with FCC radiation exposure set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 20 cm (8 inches) during normal operation.

---

**Safety**

This equipment is designed with the utmost care for the safety of those who install and use it. However, special attention must be paid to the dangers of electric shock and static electricity when working with electrical equipment. All guidelines of this and of the computer manufacture must therefore be allowed at all times to ensure the safe use of the equipment.

**CE Mark Warning**

This is a Class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

**WEEE Regulation**

To avoid the potential effects on the environment and human health as a result of the presence of hazardous substances in electrical and electronic equipment, end users of electrical and electronic equipment should understand the meaning of the crossed-out wheeled bin symbol. Do not dispose of WEEE as unsorted municipal waste and have to collect such WEEE separately.

**Revision**

User's Manual for PLANET 60fps Full HD IR IP Camera with Remote Focus and Zoom  
Model: ICA-4210P  
Rev: 1.00 (June, 2014)  
Part No. EM-ICA-4210P\_v1.0

## Table of Contents

Chapter 1. Product Introduction .....	6
1.1 Package Contents.....	6
1.2 Overview .....	6
1.3 Features.....	10
1.4 Product Specification .....	10
Chapter 2. Hardware Interface.....	13
2.1 Physical Descriptions.....	13
2.1.1 Identification of ICA-4210P physical detail.....	13
2.1.2 I/O Control Instruction.....	14
2.1.3 Connector board .....	15
2.2 Hardware Installation .....	16
2.3 Initial Utility Installation.....	17
2.4 Preparation .....	19
2.4.1 Search and View by PLANET IP Wizard II.....	19
2.4.2 Configuring Network by PLANET IP Wizard II .....	21
2.5 Using UPnP of Windows XP or 7 .....	22
2.5.1 Windows XP .....	22
2.5.2 Windows 7 .....	26
2.6 Setup ActiveX to use the Internet Camera .....	27
2.6.1 Internet Explorer 6 for Windows XP.....	28
2.6.2 Internet Explorer 7 for Windows XP.....	28
2.6.3 Internet Explorer 7 for Windows Vista.....	29
Chapter 3. Web-based Management.....	31
3.1 Introduction .....	31
3.2 Connecting to Internet Camera.....	31
3.3 Live View .....	32
3.4 ActiveX Control .....	34
3.4.1 Digital Zoom.....	35
3.4.2 Snapshot .....	35
3.4.3 Record .....	35
3.4.4 Volume.....	36
3.4.5 About .....	36
3.5 Network Configuration .....	37
3.5.1 Network .....	37
3.5.2 IPv6 .....	38
3.5.3 HTTPS.....	39
3.5.4 DDNS server .....	39
3.5.5 PPPoE .....	40
3.5.6 Streaming .....	41
3.5.7 UPnP .....	42
3.5.8 Bonjour .....	43
3.5.9 IP Filter .....	43
3.5.10 IP Notification.....	43
3.5.11 Qos .....	45
3.6 Camera Configuration.....	45
3.6.1 Picture .....	45
3.6.2 Exposure Control .....	47
3.6.3 Focus .....	48

---

3.6.4 Privacy Mask .....	48
3.6.5 PTZ Setting.....	49
3.6.6 Preset Setting .....	50
3.6.7 Tour Setting.....	50
3.7 System Configuration.....	51
3.7.1 System.....	52
3.7.2 Date & Time .....	52
3.7.3 Maintenance .....	54
3.8 Video Configuration .....	55
3.8.1 Common .....	56
3.8.2 Overlay Image .....	56
3.8.3 Video Profile .....	57
3.8.4 ONVIF Profile.....	59
3.8.5 AOI.....	60
3.9 Audio Configuration .....	61
3.10 User Configuration.....	62
3.11 Protocol Configuration.....	63
3.11.1 ONVIF .....	63
3.11.2 SNMP .....	63
3.12 E-mail Configuration .....	64
3.13 Event Detection Configuration .....	65
3.13.1 Object Detection .....	65
3.13.2 Camera Tampering .....	67
3.13.3 Audio Detection.....	68
3.13.4 Face Detection.....	68
3.13.5 Cross Line Detection .....	69
3.14 Storage Configuration .....	71
3.14.1 SD Card.....	71
3.14.2 SAMBA Server.....	72
3.15 Continuous Recording Configuration .....	72
3.16 Recording List Configuration.....	73
3.17 Event Server Configuration.....	74
3.17.1 FTP Server .....	74
3.17.2 TCP Server .....	75
3.17.3 HTTP Server.....	75
3.17.4 SAMBA Server.....	76
3.18 Event Schedule Configuration .....	77
3.18.1 Setting .....	77
3.18.2 Record .....	80
3.18.3 Port Status .....	80
Appendix A: Ping IP Address .....	81
Appendix B: 3GPP Access.....	82
Appendix C: Bandwidth and Video Size Estimation .....	83
Appendix D: DDNS Application .....	84
Appendix E: Configuring Port Forwarding Manually .....	85
Appendix F: Power Line Frequency.....	91
Appendix G: Troubleshooting & Frequently Asked Questions.....	92

## Chapter 1. Product Introduction

### 1.1 Package Contents

The package should contain the following:

- IP Camera Unit x 1
- Power Adapter x 1
- Camera Screw Kit x 1
- User's Manual CD-ROM x 1
- Quick Installation Guide x 1



1. If any of the above items are missing, please contact your dealer immediately.
2. Using the power supply that is not the one included in Internet Camera packet will cause damage and void the warranty for this product.

### 1.2 Overview

#### High Frame Rate (60fps) for Real-time Surveillance Applications

PLANET ICA-4210P Network Camera with Zero-lux Illuminator is a high-resolution camera for the round-the-clock surveillance over IP networks. It supports H.264 and JPEG compression formats and delivers excellent picture quality in Full HD resolutions at 60 frames per second (fps). Incorporating the new Exmor R<sup>TM</sup> CMOS image sensor, which is specially designed for surveillance applications, the ICA-4210P provides high-quality images under all lighting conditions. It is perfect for remote and discreet monitoring of indoor areas such as stores, banks, hotels, office lobbies and warehouses.




#### Day & Night Functionality

To adapt to constantly changing lighting conditions, the ICA-4210P comes with a removable IR-cut filter and built-in low IR illuminators (0.01 lux), which enables the camera to provide color video when there is sufficient light, and black/white video in dark conditions. The ICA-4210P is able to maintain clear images 24 hours a day.



### Exceptional Image quality

Together with powerful image processing attributes like True Wide Dynamic Range and 3D Digital Noise Reduction (3DNR) technology, the ICA-4210P is able to filter the intense backlight surrounding a subject and remove noises from video signal. It brings an extremely clear and exquisite picture quality even under any challenging lighting conditions.



### Passive Infrared (PIR) Sensor

When people pass by or in an emergency situation, the built-in PIR motion detection sensor in the ICA-4210P will “detect” and start recording automatically. It is able to detect movement as far as 6 meters away. When motion is detected in the specified areas, the additional function of alarm notification can send an e-mail alert or send captured images via FTP upload to a designated storage server.



### Smart Focus with P-Iris

The ICA-4210P comes with the Smart Focus to make installation and adjustment easier by allowing remote focus and zoom adjustment. P-iris function works by a stepping motor controlled via software to automatically provide the best iris position for the best exposure time in all lighting conditions.



### Face Detection and Cross Line Detection

Face Detection detects face and ignores anything else, such as buildings, cars and bodies. When a suspect enters a targeted area, his face is caught in the camera, thereby triggering an alarm. Cross Line Detection is an application especially suitable for general entrance and exit detection in low traffic areas. It detects objects such as persons and vehicles that cross a defined virtual line.



Face Detection



Cross Line Detection

### Camera Tampering and Audio Detection

Provided with three individually configurable motion detection zones, the ICA-4210P can record video or trigger alarms and alerts when motion is detected in user-specified areas of the camera image. Also, its external microphone enables the system to capture the sound that is out of reach of camera's surveillance range and to trigger the audio detection alarm when sounds like screams, glass breaking, etc are detected.





### Advanced Event Management

To enhance surveillance flexibility and event management capabilities, the ICA-4210P supports a number of advanced features including auto-iris to avoid over exposure, AV out to perform the two-way audio function, RS485 to connect to an optional pan/tilt enclosure which effectively supports pan/tilt functionality, and inputs/outputs to connect with external devices such as door sensors and relays to activate light or close doors.

### 2-way Audio



### Flexible Installation and Power Functionality

The ICA-4210P, incorporating IEEE 802.3af Power over Ethernet standard, is able to be powered via the network cable from a PoE power sourcing equipment such as PoE switch and PoE injector. It thus eliminates the need for extra power cables and reduces installation costs while increases the deployment flexibility. In addition, the ICA-4210P provides advanced features such as the Gigabit Ethernet transmission, giving users the utmost in bandwidth flexibility and storage efficiency. The ICA-4210P is ONVIF compliant and therefore interoperable with other manufacturers' products. It also includes 64-CH central management software for ease of maintenance and remote monitoring. The ICA-4210P is indisputably the top choice for reliable and high-performance surveillance.



## 1.3 Features

### ➤ Camera

- Sony's 1/2.8 type Exmor RS 2.4MP CMOS sensor
- 3.0~10.5 mm motorized vari-focal, P-iris lens
- Super low lux at 0.01 allows the camera to provide a color live view in near darkness
- Max. resolution 1080P at 60fps
- True WDR Enhancement to enhance visibility under extremely bright or dark environments
- Alarm will be triggered and immediately alerted to user when motion, audio, network disconnect, tampering, and face and cross line detection are detected
- Removable IR-cut filter for Day & Night function
- Built-in PIR sensor (6m/120 degrees coverage) for thermal / motion detection
- Built-in 12 IR illuminators, effective up to 20 meters
- Smart Focus for remote and precise focus adjustment

### ➤ Video / Audio

- H.264 and M-JPEG video compression simultaneously
- H.264 high profile, main profile and baseline
- Simultaneous multi-stream support
- 3DNR to improve picture quality at low lux
- Two-way audio support with enhanced audio quality

### ➤ Network and Configuration

- Compliant with IEEE 802.3af PoE interface for flexible deployment
- Equipped with Gigabit Ethernet port
- Auto MDI/MDI-X supported
- Supports both IPv6 and IPv4
- Built-in Samba client for NAS
- RTSP / UPnP / 3GPP / HTTPS protocols selectable

### ➤ Easy Installation & Management

- ONVIF compliant for interoperability
- 3GPP for 3G mobile remote applications
- Micro SD card local video recording supported
- RS485 interface for P/T scanner control
- Digital Input/Output for integration with sensors and alarms
- Cam Viewer 3 central management software supported

## 1.4 Product Specification

<b>Model</b>	ICA-4210P
<b>Camera</b>	
<b>Image Device</b>	1/2.8 type Sony Exmor RS progressive scan CMOS sensor
<b>Lens</b>	Vari-focal 3.0~10.5mm, P-Iris Mechanical IR-cut filter Angle of view : horizontal: 25 ~ 80 degrees / vertical: 19 ~ 62 degrees
<b>Min Illumination</b>	0.1 lux (color) 0.01 lux (B/W)
<b>IR Illuminations</b>	IR LED x 12, 850nm Built-in IR illuminators, effective up to 20 meters *The IR distance is based on the environment
<b>PIR Sensor</b>	Built-in 6m/120 degrees Coverage
<b>Effective Pixels</b>	1920 x 1080 pixels (Full HD)

<b>Image</b>	
<b>Video Compression</b>	H.264 / M-JPEG
<b>Video Resolution</b>	<b>1080P mode</b> H.264: 1080P / 640 x 480 M-JPEG: 1080P / 640 x 480  <b>1080P mode with WDR</b> H.264: 1080P / 640 x 480 M-JPEG: 1080P / 640 x 480
<b>Frame Rate</b>	Up to 60fps for all resolutions
<b>Image Setting</b>	AE, AWB 3D noise reduction True WDR Color, brightness, sharpness, contrast, hue Mirror/Flip 10 Privacy Masks Text, time and date overlay Overlay image on video Digital Image Stabilization (DIS)
<b>Streaming</b>	Simultaneous multi-profile streaming Streaming over UDP, TCP, HTTP, or HTTPS M-JPEG streaming over HTTP (server push) Controllable frame rate and bandwidth AOI
<b>Audio</b>	
<b>Audio Streaming</b>	Two-way audio
<b>Audio Compression</b>	RTSP: G.711 64kbps, G.726 32kbps
<b>Microphone</b>	External microphone input
<b>Audio Output</b>	Adjustable audio output gain
<b>Network and Configuration</b>	
<b>Standard</b>	IEEE 802.3 10Base-T IEEE 802.3u 100Base-TX IEEE 802.3ab 1000Base-T
<b>Protocol</b>	IPv4, IPv6, TCP, UDP, HTTP, HTTPS, SMTP, FTP, NTP, DNS, DDNS, DHCP, DIPS, ARP, Bonjour, UPnP, RTSP, RTP, RTCP, IGMP, PPPoE, Samba, ICMP, SNMP, QoS
<b>Security</b>	Password protection, IP address filtering, HTTPS encrypted data transmission, user access log
<b>Users</b>	20 clients on-line monitoring at the same time
<b>System Integration</b>	
<b>Application Programming Interface</b>	Open API for software integration ONVIF Compliant
<b>Alarm Triggers</b>	Intelligent Motion / Tampering / Audio / Face / Cross line detection and external input
<b>Alarm Events</b>	File upload via FTP, Samba to NAS, SD card or email Notification via email, HTTP, and TCP External output activation Audio alert output Go to PTZ preset position
<b>Video Buffer</b>	Pre- and post-alarm buffering
<b>General</b>	
<b>Power Requirements</b>	12V DC, 1A

	IEEE 802.3af Class 3
<b>Power Consumption</b>	9W max.
<b>Operating Temperature</b>	0 ~ 50 degrees C
<b>Operating Humidity</b>	20 ~ 80% (non-condensing)
<b>Weight</b>	635g
<b>Dimensions (Φ x L)</b>	152 x 109mm
<b>Emission</b>	CE, FCC
<b>Connectors</b>	10/100/1000 Mbps Gigabit Ethernet, RJ-45 DC power jack Terminal block for 1 alarm input and 1 output RS-485 interface for scanners, pan/tilt External mic input Audio out Micro SD/SDHC card (max. 32GB, Class 6) Factory default reset button


## Chapter 2. Hardware Interface

### 2.1 Physical Descriptions

#### 2.1.1 Identification of ICA-4210P physical detail


##### Real Panel





Item	Description
Lens	Keep the lens clean to keep excellent video quality.
IR LED	Emits infrared light to provide light source in dark places
Light Sensor	<p>Detects the illumination level or the place where this IP camera is installed, and switches IR LEDs on when it's required.</p> <div>  <p>When IR LEDs are switched on, this IP camera will switch to black and white video mode to enhance video quality. Do not cover light sensor or this IP camera will work in black and white mode only.</p> </div>
PIR	PIR sensor is used to sense motion or detect whether a human has moved in or out of the sensors range.



## 2.1.2 I/O Control Instruction




### Descriptions for I/O cable set:

Interface	Description
<b>DC Power</b>	<p>The input power is DC 12V, 1A.</p> <p> <b>Note</b> ONLY use package power adapter supplied with the internet. Otherwise, the product may be damaged.</p>
<b>RJ45 (LAN socket, PoE )</b>	<p>Connecting to PC or Hub/Switch. For connection to 10Base-T Ethernet or 100Base-TX or 1000Base-T Fast Ethernet cabling, this Ethernet port built auto-negotiation protocol can detect or negotiate the transmission speed of the network automatically. Please use CAT-5 cable to connect the Network Camera to a 1000Mbps Fast Ethernet network switch or hub.</p> <p> <b>Note</b> ONLY use one power source, either from DC or from 802.3af Power over Ethernet.</p>
<b>Audio Output (Green, Line Out)</b>	Connecting a loud speaker to the IP Camera. This is for voice alerting and two-way audio.
<b>Microphone Input (Pink, Audio In)</b>	Connect a microphone to the IP Camera.
<b>Reset (Factory Default)</b>	This button is used to restore all the factory default settings.
<b>DI/DO, RS-485</b>	The 6 pin terminal block includes 1 input port and 1 output port, and RS-485 D+ and D-.



Terminal block for I/O connectors:

Name	Cable Color	Function
12VDC	1	DC 12V (50mA maximum)
DI	2	Digital signal input
GND	3	GND
DO	4	Digital signal output
485+	5	RS485 data +
485-	6	RS485 data -

### 2.1.3 Connector board



Interface	Description		
Terminal block	Pin	Name	Function
	1	12VDC in	DC 12V power input
	2	MIC in-	External MIC input-
	3	MIC in+	External MIC input+
	4	Audio out+	
	5	Audio out-	
	6	GND	Ground
	7	12VDC out	DC 12V output (50mA maximum)
	8	DI	Digital signal input
	9	GND	Ground

	10	DO	Digital signal output
	11	RS485+	RS485 data +
	12	RS485-	RS485 data -
<b>RJ45 (LAN socket, PoE )</b>	<p>Connecting to PC or Hub/Switch. For connection to 10Base-T Ethernet or 100Base-TX or 1000Base-TX Fast Ethernet cabling, this Ethernet port built auto-negotiation protocol can detect or negotiate the transmission speed of the network automatically. Please use CAT-5 cable to connect the Network Camera to a 1000Mbps Fast Ethernet network switch or hub.</p> <div>  ONLY use one power source, either from DC or from 802.3af Power over Ethernet. </div>		
<b>12V DC in &amp; Power GND</b>	<p>The input power is DC 12V, 1A.</p> <div>  ONLY use the power adapter supplied in the package. Otherwise, the product may be damaged. </div>		
<b>Mic in (audio in)</b>	Connect an external microphone to the camera.		
<b>Audio out +/-</b>	Connect a loud speaker to the camera. This function is for voice alert and two-way audio.		
<b>Video out</b>	Connect a TV monitor to the camera. User can check the focus/zoom and view angle of the camera.		
<b>DI/GND/DO/RS485</b>	The 6 pin terminal block includes 1 input port and 1 output port, and RS-485 D+ and D-.		
<b>Factory Default Reset</b>	<p>This button is used to restore all the factory default settings. Restore the device:</p> <ol style="list-style-type: none"> <li>Press the button down continuously.</li> <li>Hold the button for at least 5 seconds and release it. Then the device has been restored to default settings and reboot again.</li> </ol>		
<b>Micro SD Card Slot</b>	User can insert a micro SD card into this slot for recording.		

## 2.2 Hardware Installation

### 1. Attach the Camera with the included stand

### 2. Place the Camera on the ceiling or fix it onto wall


Use three screws to fix the Network Camera onto the ceiling or wall.

### 3. Plug an Ethernet cable into the Camera

Connect an Ethernet cable to the LAN socket located on the Network Camera's bottom and attach it to the network.

### 4. Connecting the external power supply to Camera

Connect the attached power adapter to the DC power jack of the IP Camera.



Use the 12V DC power adapter included in the package to connect it to wall outlet for AC power.


### 5. Done

Once you have installed the IP Camera well and powered it on, the network accessing type LED will turn on. It means the system is booting up successfully. Furthermore, if you have a proper network connection, and access to the IP Camera, the LED will flash green in the wired mode or orange in the wireless mode.


## 2.3 Initial Utility Installation

This chapter shows how to quickly set up your IP camera. The camera is with the default settings. However to help you find the networked camera quickly the windows utility PLANET IP Wizard II can search the cameras in the network that can help you to configure some basic setting before you started advanced management and monitoring.


1. Insert the bundled CD into the CD-ROM drive to launch the auto-run program. Once completed, a welcome menu screen will appear.
2. Click the “IP Wizard II” hyperlink and a dialog box will appear as shown below:

  
Note


If the welcome screen does not appear, click “Start” at the taskbar. Then, select “Run” and type “D:\Utility\IPWizard II\setup.exe”, assuming D is your CD-ROM drive.




3. The “Welcome to the Install Shield Wizard for PLANET IP Wizard II” prompt will display on the screen and click “**Next**” to continue.



- Please click **"Next"** to install with original settings, or you may click **"Change..."** button to modify the install folder then press **"Next"** to continue.




- Please click **"Install"** to start the installation.





6. Please click **"Finish"** to complete the installation and launch program immediately.




## 2.4 Preparation

When you install the Internet Camera in a LAN environment, you may execute PLANET IP Wizard II to discover camera's IP address and set up related parameters in the camera.

### 2.4.1 Search and View by PLANET IP Wizard II

When you install the Internet Camera in a LAN environment, you have two easy ways to search your cameras either by PLANET IP Wizard II or UPnP discovery. Here is the way to execute PLANET IP Wizard II to discover camera's IP address and set up related parameter in a camera.

#### Search





When launching the Planet IP Wizard II, the "searching" window will pop up. Planet IP Wizard II is starting to search Internet Cameras on the LAN. The existing devices are listed as below.


PLANET IP Wizard II Version 3.0.0.6043 Interface : 10.1.1.206


Device Title	IP Address	Port	MAC
PLANET IP Camera	10.1.1.98	80	00-30-4F-A2-92-70

Searching...

**SEARCH** 

**VIEW** 

**LAN** 

**WIRELESS** 

**EXIT**

**Camera:**

Model Name: ICA-4210P

Network: Wired

DHCP: ON

WiFi: Ethernet Only

Connection: Not Connected

Device ID (for DIPS): N/A

User Name: admin

Password: AAAAA


Off-Line


### View


If Planet IP Wizard II finds Internet Camera, the View button will be available. Please select the camera you want to view and click the View button. Then you can see the video from the camera directly. Furthermore you can double-click the left button of the mouse to link to the Internet Camera by browser.


PLANET IP Wizard II Version 3.0.0.6043 Interface : 10.1.1.206

Device Title	IP Address	Port	MAC
PLANET IP Camera	10.1.1.98	80	00-30-4F-A2-92-70

**SEARCH** 

**VIEW** 

**LAN** 

**WIRELESS** 

**EXIT**

**Camera:**

Model Name: ICA-4210P

Network: Wired

DHCP: ON


WiFi: Ethernet Only

Connection: Success

Device ID (for DIPS): N/A


User Name: admin

Password: AAAAA



## 2.4.2 Configuring Network by PLANET IP Wizard II

In case you want to change the IP related parameters of wired interface, please select the Internet Camera you want to configure and click the LAN button. Related settings will be carried out as shown below.



Device Title | IP Address | Port | MAC

PLANET IP Camera	10.1.1.98	80	00-30-4F-A2-92-70
------------------	-----------	----	-------------------

SEARCH VIEW LAN WIRELESS EXIT

LAN:

Network: ☐ Static IP ☒ DHCP IP

IP Address: 10 . 1 . 1 . 98

Subnet Mask: 255 . 255 . 255 . 0

Gateway: 10 . 1 . 1 . 254

DNS1: 168 . 95 . 1 . 1

DNS2: 168 . 95 . 1 . 2


User Name: admin

Password: \*\*\*\*\*

Off-Line

In case, you do not want to change username and/or password, then just click the **"Submit"** button to perform your setting accordingly. Click the **"<<"** button to go back to the previous page.

If you like to change username and/or password of the device, just click the check button. Then, the related fields will show up as shown below.



Device Title | IP Address | Port | MAC

PLANET IP Camera	10.1.1.98	80	00-30-4F-A2-92-70
------------------	-----------	----	-------------------

SEARCH VIEW LAN WIRELESS EXIT

User:

☒ Change Password

User Name: admin

New Password:

Confirm Password:

User Name: admin

Password:

Submit

After keying in the new username and password, click the “**Submit**” button to perform your setting accordingly. Click the “<<” button to go back to the previous page.

## 2.5 Using UPnP of Windows XP or 7


### 2.5.1 Windows XP

UPnP™ is short for Universal Plug and Play, which is a networking architecture that provides compatibility among networking equipment, software, and peripherals. This device is an UPnP enabled device. If the operating system, Windows XP, of your PC is UPnP enabled, the device will be very easy to configure. Use the following steps to enable UPnP settings only if your operating system of PC is running Windows XP.




Please note that MS Windows 2000 does not support UPnP feature.


Go to **Start > Settings**, and Click **Control Panel**.




The “**Control Panel**” will display on the screen and double-click “**Add or Remove Programs**” to continue.



The “Add or Remove Programs” will display on the screen and click **Add/Remove Windows Components** to continue.



The following screen will appear, select “**Networking Services**” and click “**Details**” to continue.







The “Networking Services” will display on the screen, select “**Universal Plug and Play**” and click “**OK**” to continue.



Please click “**Next**” to continue.




The program will start installing the UPnP automatically. You will see the pop-up screen below. Please wait while Setup configures the components.



Please click **Finish** to complete the UPnP installation





Double-click **"My Network Places"** on the desktop, the "My Network Places" will display on the screen and double-click the UPnP icon with Internet Camera to view your device in an Internet browser.





## 2.5.2 Windows 7

Go to **Start > Control Panel > Network and Internet > Network and Sharing Center**, if network discovery is off; click the arrow button  to expand the section.

Click Turn on network discovery, and then click Apply.  If you are prompted for an administrator password or confirmation, type the password or provide confirmation.





## 2.6 Setup ActiveX to use the Internet Camera


The Internet Camera web pages communicate with the Internet Camera using an ActiveX control. The ActiveX control must be downloaded from the Internet Camera and installed on your PC. Your Internet Explorer security settings must allow for the web page to work correctly. To use the Internet Camera, user must setup his IE browser as follows:

## 2.6.1 Internet Explorer 6 for Windows XP

From your IE browse → "Tools" → "Internet Options..." → "Security" → "Custom Level...", please setup your "Settings" as follows:

Set the first 3 items

- Download the signed ActiveX controls
- Download the unsigned ActiveX controls
- Initialize and script the ActiveX controls not masked as safe to Prompt



By now, you have finished your entire PC configuration for Internet Camera.


## 2.6.2 Internet Explorer 7 for Windows XP

From your IE browse → "Tools" → "Internet Options..." → "Security" → "Custom Level...", please setup your "Settings" as follows:

Set the first 3 items

- Allow previously unused ActiveX control to run...
- Allows Scriptlets
- Automatic prompting for ActiveX controls







By now, you have finished your entire PC configuration for Internet Camera.

### 2.6.3 Internet Explorer 7 for Windows Vista



From your IE browse → "Tools" → "Internet Options..." → "Security" → "Internet" → "Custom Level...", please setup your "Settings" as follows:

- Enable "Automatic prompting for ActiveX controls"
- Prompt "Initialize and script active controls not marked..."



From your IE browse → "Tools" → "Internet Options..." → "Security" → "Trusted Sites" → "Custom Level...", please setup your "Settings" as follows:

- Enable "Automatic prompting for ActiveX controls"
- Prompt "Initialize and script active controls not marked..."



By now, you have finished your entire PC configuration for Internet Camera.

## Chapter 3. Web-based Management

This chapter provides setup details of the Internet Camera's Web-based Interface.

### 3.1 Introduction


The Internet Camera can be configured with your Web Browser. Before configure, please make sure your PC is under the same IP segment with Internet Camera.

### 3.2 Connecting to Internet Camera


- A. Use the following procedure to establish a connection from your PC to the Internet Camera.
- B. Once connected, you can add the camera to your Browser's Favorites or Bookmarks.

Start the web browser on the computer and type the IP address of the camera.

The Default IP: "<http://192.168.0.20/>"




The login window of Internet Camera will appear,  
Default login **username** and **password** are both **admin**.




If the user name and password have been changed with PLANET IP Wizard II, please enter the new user name and password here.

After logging on, you should see the following messages at the top of Internet Explorer:



Click on the message, and click **Run Add-on**




When you see this message, click **Run** to install the required ActiveX control




After the ActiveX control has been installed and run, the first image will be displayed.

You should be able to see the images captured from the Internet Camera on the web page now. For advanced functions, please refer to instructions given in the following chapters.

	<p>If you log in the camera as an ordinary user, setting function will be not available. If you log in the camera as the administrator, you can perform all the settings provided within the device.</p>
---	--

### 3.3 Live View

Start-up screen will be as follows whether you are an ordinary user or an administrator.



#### Image Monitoring Section

The image shot by the camera is shown here. The date and time are displayed at the top of the window.

#### Video Profile

The camera support multi-profile for three compressions H264 and M-JPEG simultaneously. User can chose the proper and/or preferred profile here.

#### Full Screen

Click this button to display the image in full-screen mode (uses every available space to display the image captured by this camera).

#### 2-way Audio

The Internet Camera supports 2-way audio function. User can chose to enable or disable this function by toggling the icon below



: Disable audio uploading function.



: Enable audio uploading function.

#### ActiveX Control

The plug-in ActiveX control supports a lot of functions by clicking the left mouse button. Note that this feature only supports on the ActiveX control within Microsoft® Internet Explorer.

#### Setting Menu

This function is in a detailed setting for the camera that only available for user logged into camera as administrator.

Item	Action
Network	Configure Network settings such as IPv6, ONVIF, DHCP, DDNS, 3GPP, PPPoE and UPnP.
Camera	Adjust camera parameters.
System	Configure system information, date and time, maintenance, and view system log file.
Video	Configure bit rate and frame rate of video profiles.

Audio	Configure audio parameters.
User	Set up user name, password and login privilege.
Protocol	Set up ONVIF and SNMP configuration.
E-mail	Set up e-mail configuration.
Event Detection	Set up object detection.
Storage	Status and configuration of SD card and Samba server.
Continuous Recording	Files list inside the SD Card and Samba server.
Recording List	Files list inside the SD Card.
Event Server	Set up FTP/TCP/HTTP/Samba server for event
Event Schedule	Configure the schedule while event triggered.
<b>Streaming Protocol</b>	User can select proper streaming protocol according to networking environment.
<b>Language</b>	The device can provide multiple languages to meet customer's requirements.
<b>Client Setting:</b>	Click this button to display the client extra control panel for 2-way Audio and Full Screen.
<b>Video Information</b>	Display video information including video format, resolution, frame rate and bit rate.

### 3.4 ActiveX Control

The plug-in ActiveX control supports a lot of functions by clicking the left mouse button. Note that this feature only supports on the ActiveX control within Microsoft® Internet Explorer.

On the ActiveX control icon, click the Left Mouse Button, then a menu pop-up. This menu provides features that are unique to the ActiveX control. These features include:


- Digital Zoom,
- Snapshot,
- Record,
- Volume,
- About





### 3.4.1 Digital Zoom


Click **Digital Zoom** to activate this function shown below. User can drag or scale the box over the video to adjust zoom ratio and position.



### 3.4.2 Snapshot

Click **Snapshot** to activate this function. Press **Snapshot** button to take a picture. The image file is saved as JPEG format into your local PC. Select **Browser**, the pop-up window to select the save path and file name prefix, and select **OK** to continue.

If you like to retrieve the saved image, select the file to display the saved image by using any of the graph editing tools.



### 3.4.3 Record

Click **Record** to activate this function. Press **Record** button to start recording. The video file is saved as ASF format into your local PC. If you want to stop it, press **Stop** to stop recording. Select **Browser**, the pop-up window to select the save path and file name prefix, and select **OK** to continue.


After recording is stopped, list the files. This file is named as Video\_yyyymmddhhmmss.asf . The ASF files can be displayed by the standard

Windows Media Player, but it needs the DixectX 9.0 or later version to be installed.




### 3.4.4 Volume

Click Volume to activate this function. These have two control bars for speaker and microphone volume. Scroll this control bar to adjust the audio attribute. Check the volume mute to mute the speaker output.



### 3.4.5 About

Click "**About**" to show the ActiveX information



## 3.5 Network Configuration

Use this menu to configure the network to connect the device and the clients.

### 3.5.1 Network

This section provides the menu of connecting the device through Ethernet cable.

Network	IPv6	HTTPS	DDNS	PPPoE	Streaming	UPnP	Bonjour	IP Filter	IP Notification	QoS
<p>MAC Address: 00:30:4F:A3:58:EA</p> <p><input checked="" type="checkbox"/> Obtain IP address automatically (DHCP)</p> <p>IP Address: 192.168.0.11 <span>Test</span></p> <p>Subnet Mask: 255.255.255.0</p> <p>Gateway: 192.168.0.1</p> <p><input checked="" type="checkbox"/> Obtain DNS from DHCP</p> <p>Primary DNS: 192.168.0.1</p> <p>Secondary DNS: 8.8.8.8</p> <p>HTTP Port: 80 (1 ~ 65535) <span>Test</span></p>										

#### MAC Address

Display the Ethernet MAC address of the device. Note that user cannot change it.

#### Obtain an IP address automatically (DHCP)

Enable this checked box when a DHCP server is installed on the network to issue IP address assignment. With this setting, the IP address is assigned automatically. If this device cannot get an IP address within limited tries, the device will assign a default IP address for 192.168.0.20.

If you do not select "Obtain an IP address automatically", then you need to enter these network parameters by yourself.

#### IP Address

This address is a unique numbers that identifies a computer or device on the WAN or LAN. These numbers are usually shown in groups separated by periods, for example: 192.168.0.200

#### Subnet Mask

Subnets allow network traffic between hosts to be separated based on the network's configuration. In IP networking, traffic takes the form of packets. IP subnets advance network security and performance to some level by organizing hosts into logical groups. Subnet masks contain four bytes and usually appear in the same "dotted decimal" data. For example, a very common subnet mask in its binary demonstration 11111111 11111111 11111111 00000000 will usually be shown in the corresponding, more readable form as 255.255.255.0.

#### Gateway

A gateway is a piece of software or hardware that passes information between networks. You'll see this term most often when you either

log in to an Internet site or when you're transient email between different servers.

**Obtain DNS from DHCP**

Enable this checked box when a DHCP server is installed on the network and provide DNS service.

**Primary DNS**

When you send email or position a browser to an Internet domain such as xxxxx.com, the domain name system translates the names into IP addresses. The term refers to two things: the conventions for naming hosts and the way the names are control across the Internet.

**Secondary DNS**

The same function as DNS1. It is optional.

**HTTP Port**


The device supports two HTTP ports. The first one is default port 80 and this port is fixed. This port is very useful for Intranet usage. The second HTTP port is changeable. Users could assign the second port number of http protocol, and the WAN users should follow the port number to login. If the http port is not assigned as 80, users have to add the port number in the back of IP address. For example: <http://192.168.0.20:8080>.

Therefore, the user can access the device by either

<http://xx.xx.xx.xx/>, or

<http://xx.xx.xx.xx:xxxx/> to access the device.

If multiple devices are installed on the LAN and also required to be accessed from the WAN, then the **HTTP Port** can be assigned as the virtual server port mapping to support multiple devices.



If you log in the camera as an ordinary user, setting function will be not available. If you log in the camera as the administrator, you can perform all the settings provided within the device.

When the configuration is finished, please click "**OK**" to save and enable the setting.

### 3.5.2 IPv6

Internet Protocol version 6 (IPv6) is called the "IP Next Generation" (IPng), which is designed to fix the shortcomings of IPv4, such as data security and maximum number of user addresses. It is backward compatible and thus expected to slowly replace IPv4, with the two existing side by side for many years.

Network	<b>IPv6</b>	HTTPS	DDNS	PPPoE	Streaming	UPnP	Bonjour	IP Filter	IP Notification	QoS
<div>IPv6</div> <div> <input checked="" type="radio"/> Disable         <input type="radio"/> Enable       </div>										

## IPv6

To enable or disable the IPv6 function here.

### 3.5.3 HTTPS

HTTPS: Stands for Hypertext Transfer Protocol Secure

HTTPS is a combination of the Hypertext Transfer Protocol with the SSL/TLS protocol to provide encrypted communication and secure identification of a network web server. HTTPS connections are often used for sensitive transactions in corporate information systems. The main idea of HTTPS is to create a secure channel over an insecure network. This ensures reasonable protection from eavesdroppers and man-in-the-middle attacks, provided that adequate cipher suites are used and that the server certificate is verified and trusted.

Network	IPv6	HTTPS	DDNS	PPPoE	Streaming	UPnP	Bonjour	IP Filter	IP Notification	QoS
<div> <div>HTTPS</div> <div> <input checked="" type="radio"/> Disable           <input type="radio"/> Enable         </div> </div> <div> <div>Port</div> <div> <input type="text" value="443"/> (1 ~ 65535) <input type="button" value="Test"/> </div> </div>										

## HTTPS

To enable or disable the HTTPS service here. Note that the HTTPS function of this device is not only encrypted the web content but also audio/video data.

## Port

Choose the HTTPS port. The default value is 443.

### 3.5.4 DDNS server

Stands for Dynamic Domain Name Server

The device supports DDNS If your device is connected to xDSL directly. You might need this feature. However, if your device is behind a NAT router, you will not need to enable this feature. Because DDNS allows the device to use an easier way to remember naming format rather than an IP address. The name of the domain is like the name of a person, and the IP address is like his phone number. On the Internet we have IP numbers for each host (computer, server, router, and so on), and we replace these IP numbers to easily remember names, which are organized into the domain name. As to xDSL environment, most of the users will use dynamic IP addresses. If users want to set up a web or a FTP server, then the Dynamic Domain Name Server is necessary. For more DDNS configuration, please consult your dealer.

Your Internet Service Provider (ISP) provides with you at least one IP address which is used to connect to the Internet. The address you get may be static, meaning it never changes, or dynamic, meaning it's likely to change periodically. Just how often it changes, depending on your ISP. A dynamic IP address complicates remote access since you may not know what your current WAN IP address is when you want to access your network over the Internet. The solution to the dynamic IP address problem comes in the form of a dynamic DNS service.

The Internet uses DNS servers to lookup domain names and translates them into IP addresses. Domain names are just easy to remember aliases for IP addresses. A dynamic DNS service is unique because it provides a means of updating your IP address so that your listing will remain current when your IP address changes. There are several excellent DDNS services available on the Internet and best of all they're free to use. One such service you can use is [www.DynDNS.org](http://www.DynDNS.org). You'll need to register with the service and set up the domain name of your choice to begin using it. Please refer to the home page of the service for detailed instructions or refer to Appendix E for more information.

Network	IPv6	HTTPS	DDNS	PPPoE	Streaming	UPnP	Bonjour	IP Filter	IP Notification	QoS
<p>DDNS <input type="radio"/> Disable <input checked="" type="radio"/> Enable</p> <p>Server Name <input type="text" value="PLANET DDNS"/></p> <p>DDNS Host <input type="text" value="brandonw"/> .planetddns.com (6 ~ 16 Digits )</p> <p>User Name <input type="text" value="brandonw"/> (6~16 Digits)</p> <p>Password <input type="password" value="*****"/> (6~16 Digits)</p> <p>Internet Status Connected (123.194.107.27)</p>										

<b>DDNS</b>	To enable or disable the DDNS service here.
<b>Server Name</b>	Choose the built-in DDNS server.
<b>DDNS Host</b>	The domain name is applied for this device.
<b>User Name</b>	The user name is used to log into DDNS.
<b>Password</b>	The password is used to log into DDNS.

This model comes with Planet easy DDNS. When this function is enabled, DDNS hostname will appear automatically. User doesn't go to [www.planetddns.com](http://www.planetddns.com) to apply for a new account.

Network	IPv6	HTTPS	DDNS	PPPoE	Streaming	UPnP	Bonjour	IP Filter	IP Notification	QoS
<p>DDNS <input type="radio"/> Disable <input checked="" type="radio"/> Enable</p> <p>Server Name <input type="text" value="PLANET Easy DDNS"/></p> <p>DDNS Host <input type="text" value="pla358ea.planetddns.com"/></p> <p>Internet Status Connected (123.194.107.27)</p>										

### 3.5.5 PPPoE

PPPoE: Stands for Point to Point Protocol over Ethernet

A standard builds on Ethernet and Point-to-Point network protocol. It allows Internet Camera connect to Internet with xDSL or cable connection; it can dial up your ISP and get a dynamic IP address. For more PPPoE and Internet configuration, please consult your ISP.

It can directly connect to the xDSL, however, it should be set up in a LAN environment to program the PPPoE information first, and then connect to the xDSL modem. Power it on again to enable device dial on to the ISP for connecting to the WAN through the xDSL modem.

The procedures are

- Connect to a LAN by DHCP or Fixed IP
- Access the device by entering **Setting** → **Network** → **PPPoE** as shown below:



Network	IPv6	HTTPS	DDNS	PPPoE	Streaming	UPnP	Bonjour	IP Filter	IP Notification	QoS
<p>PPPoE <input checked="" type="radio"/> Disable <input type="radio"/> Enable</p> <p>User Name <input type="text"/> (&lt; 65 Digits)</p> <p>Password <input type="text"/> (&lt; 65 Digits)</p> <p>IP Address <input type="text"/> (readonly)</p> <p>Subnet Mask <input type="text"/> (readonly)</p> <p>Gateway <input type="text"/> (readonly)</p> <p>Status <input type="text"/> (readonly)</p>										

**PPPoE** To enable or disable the PPPoE service here.

**User Name** Type the user name for the PPPoE service which is provided by ISP.

**Password** Type the password for the PPPoE service which is provided by ISP.

**IP Address / Subnet Mask / Gateway** Shows the IP information got from PPPoE server site.

**Status** Shows the Status of PPPoE connection.

### 3.5.6 Streaming

RTSP is a streaming control protocol, and a starting point for negotiating transports such as RTP, multicast and Unicast, and for negotiating codes. RTSP can be considered a "remote control" for controlling the media stream delivered by a media server. RTSP servers typically use RTP as the protocol for the actual transport of audio/video data.

Network	IPv6	HTTPS	DDNS	PPPoE	Streaming	UPnP	Bonjour	IP Filter	IP Notification	QoS
<p>RTSP Port <input type="text" value="554"/> (554 ~ 65535) <input type="button" value="Test"/></p> <p>RTP Port <input type="text" value="50000"/> ~ <input type="text" value="50999"/> (1024 ~ 65535)</p>										

**RTSP Port** Choose the RTSP port. The RTSP protocol allows a connecting client to start a video stream. Enter the RTSP port number to use. The default value is 554.

**RTP Port** Specify the range of transmission port number of video stream. The default range is 50000 to 50999. User can specify a number between 1024 and 65535.



- To use the 3GPP function, in addition to previous section, you might need more information or configuration to make this function work.
- The camera must be set as multi-profile mode, not mega-pixel mode. Otherwise this device cannot serve 3GPP stream.

3. To use the 3GPP function, it is strongly recommended to install the Networked Device with a public and fixed IP address without any firewall protection.
4. Port 554 is the default for RTSP service. However, sometimes, some service providers change this port number for some reasons. If so, user needs to change this port accordingly.

**Dialing procedure**

1. Choose a verified player (PacketVideo, QuickTime or Real player)
2. Use the following URL to access: **rtsp://host/mpeg4/media.3gp**  
Where host is the host name or IP address of the camera.

**Compatible 3G mobile phone**

Please contact your dealer to get the approved list of compatible 3G phone.

### 3.5.7 UPnP

UPnP is short for Universal Plug and Play, which is a networking architecture that provides compatibility among networking equipment, software, and peripherals. This device is an UPnP enabled Internet Camera. If your operating system is UPnP enabled, the device will automatically be detected and a new icon will be added to "My Network Places." If you do not want to use the UPnP functionality, it can be disabled

In addition, this device also provides UPnP IGD function for NAT traversal easily. Use NAT traversal when your device is located on an intranet (LAN) and you wish to make it available from the other (WAN) side of a NAT router. With NAT traversal properly configured, all HTTP traffic to an external HTTP port in the NAT router will be forwarded to the device.

Network	IPv6	HTTPS	DDNS	PPPoE	Streaming	UPnP	Bonjour	IP Filter	IP Notification	QoS
<p><b>UPnP</b> <input type="radio"/> Disable <input checked="" type="radio"/> Enable</p> <p><b>Friendly Name</b> <input type="text" value="ICA-4210P - 00304FA358EA"/> (readonly)</p> <p><b>UPnP NAT Traversal</b> <input checked="" type="radio"/> Disable <input type="radio"/> Enable</p> <p><b>Port Range</b> <input type="text" value="32768"/> ~ <input type="text" value="65535"/> (1 ~ 65535)</p> <p><b>External IP Address</b> <input type="text"/> (readonly)</p>										

**UPnP** To enable or disable the UPnP service here.

**Friendly Name** Shows the friendly name of this device here.

**UPnP NAT Traversal** When enabled, the device will attempt to configure port mapping in a NAT router on your network, using UPnP™. Note that UPnP™ must be enabled in the NAT router first.

**Port Range** The port range will open in NAT router.

**External IP address** Show the IP address and port for WAN access through Internet. If NAT traversal is configured successfully, user can use this IP address and port to access this device.

### 3.5.8 Bonjour

The Bonjour service allows IP camera to be discovered with Apple Safari browser applied. Once the option is enabled, the IP camera will show the Friendly Name in the Bonjour bookmarks menu of Safari browser.

Network	IPv6	HTTPS	DDNS	PPPoE	Streaming	UPnP	Bonjour	IP Filter	IP Notification	QoS
---------	------	-------	------	-------	-----------	------	---------	-----------	-----------------	-----

Bonjour ☐ Disable ☒ Enable

Friendly Name  (readonly)

**Bonjour** To enable or disable the Bonjour service here.

**Friendly Name** Shows the friendly name of this device here.

### 3.5.9 IP Filter

You can enter different user's IP addresses by entering allow or deny.

Network	IPv6	HTTPS	DDNS	PPPoE	Streaming	UPnP	Bonjour	IP Filter	IP Notification	QoS
---------	------	-------	------	-------	-----------	------	---------	-----------	-----------------	-----

IP Filter ☒ Disable ☐ Enable

IP Filter Policy ☐ Deny ☒ Allow

Filter IP List

Filter IP	<input type="text"/>
<input type="button" value="Add"/> <input type="button" value="Delete"/> <input type="button" value="DeleteAll"/>	

**IP Filter** To enable or disable the IP filter function here.

**IP Filter Policy** Choose the filter policy where deny or allow is.

### 3.5.10 IP Notification

In case the IP address is changed, system is able to send out an email to alert someone if the function is enabled.

Network	IPv6	HTTPS	DDNS	PPPoE	Streaming	UPnP	Bonjour	IP Filter	IP Notification	QoS
<p><b>SMTP Notification(email)</b> <input checked="" type="radio"/> Disable <input type="radio"/> Enable</p> <p><b>Send To</b> <input type="text"/> (&lt; 129 Digits)</p> <p><b>Subject</b> <input type="text" value="IP notification"/> (&lt; 65 Digits)</p> <p><b>TCP Notification</b> <input checked="" type="radio"/> Disable <input type="radio"/> Enable</p> <p><b>TCP Server</b> <input type="text"/> (&lt; 65 Digits)</p> <p><b>TCP Port</b> <input type="text"/> (1 ~ 65535)</p> <p><b>Message</b> <input type="text"/> (&lt; 65 Digits)</p> <p><b>HTTP Notification</b> <input checked="" type="radio"/> Disable <input type="radio"/> Enable</p> <p><b>URL</b> <input type="text" value="http://"/> (&lt; 61 Digits)</p> <p><b>HTTP Login Name</b> <input type="text"/> (&lt; 22 Digits)</p> <p><b>HTTP Login Password</b> <input type="text"/> (&lt; 22 Digits)</p> <p><b>Proxy Address</b> <input type="text"/> (&lt; 129 Digits)</p> <p><b>Proxy Port</b> <input type="text"/> (1 ~ 65535)</p> <p><b>Proxy Login Name</b> <input type="text"/> (&lt; 22 Digits)</p> <p><b>Proxy Login Password</b> <input type="text"/> (&lt; 22 Digits)</p>										

<b>SMTP Notification (e-mail)</b>	If this function is enabled, the “ <b>Send to</b> ” and “ <b>Subject</b> ” field need to be filled.
<b>Send To</b>	Type the receiver’s e-mail address. This address is used for reply mail.
<b>Subject</b>	Type the subject/title of the E-mail.
<b>TCP Notification</b>	If this function is enabled, the “ <b>TCP Server</b> “, “ <b>TCP Port</b> “, and “ <b>Message</b> ” fields need to be filled.
<b>TCP Server</b>	Type the server name or the IP address of the TCP server.
<b>TCP Port</b>	Set port number of TCP server.
<b>Message</b>	The message will be sent to FTP server.
<b>HTTP Notification</b>	If this function is enabled, the fields below need to be filled.
<b>URL</b>	Type the server name or the IP address of the HTTP server
<b>HTTP Login Name</b>	Type the user name for the HTTP server.
<b>HTTP Login Password</b>	Type the password for the HTTP server.
<b>Proxy Address</b>	Type the server name or the IP address of the HTTP Proxy.
<b>Proxy Port</b>	Set port number of Proxy.
<b>Proxy Login Name</b>	Type the user name for the HTTP Proxy.

<b>Proxy Login Password</b>	Type the password for the HTTP Proxy.
<b>Custom Parameter</b>	User can set specific parameters to HTTP server.
<b>Message</b>	The message will be sent to HTTP server.

### 3.5.11 Qos


Network	IPv6	HTTPS	DDNS	PPPoE	Streaming	UPnP	Bonjour	IP Filter	IP Notification	QoS
<div>Live Video DSCP <input type="text" value="0"/> (0 ~ 63)</div> <div>Live Audio DSCP <input type="text" value="0"/> (0 ~ 63)</div> <div>Event/Alarm DSCP <input type="text" value="0"/> (0 ~ 63)</div> <div>Management DSCP <input type="text" value="0"/> (0 ~ 63)</div>										

## 3.6 Camera Configuration

Use this menu to set the function of the camera of Internet Camera


### 3.6.1 Picture

Picture	Exposure Control	Focus	Privacy Mask	PTZ Setting	Preset Setting	Tour Setting
<div>Rotation <input type="text" value="Mirror + Vertical Flip"/></div> <div>White Balance <input type="text" value="Auto"/></div> <div>Color Level <input type="text" value="50"/> (0 ~ 100)</div> <div>Hue <input type="text" value="50"/> (0 ~ 100)</div> <div>Brightness <input type="text" value="50"/> (0 ~ 100)</div> <div>Contrast <input type="text" value="50"/> (0 ~ 100)</div> <div>Sharpness <input type="text" value="50"/> (0 ~ 100)</div> <div>ICR <input checked="" type="radio"/> Photo Sensor <input type="radio"/> Manual</div> <div>DIS <input type="radio"/> Off <input checked="" type="radio"/> On</div> <div>3D De-Noise Strength <input type="text" value="3"/></div> <div>Strength of the moving subjects <input type="text" value="1"/></div> <div>2D De-Noise <input type="text" value="1"/></div> <div>Default Settings <input type="button" value="Default Settings"/></div>						



#### Rotation

Turn the “**Mirror**” and “**Vertical Flip**” On or OFF. The image will be overturned as shown below.



**White Balance** Auto: will adjust the white balance automatically.  
Hold: will hold the white balance.

**Color Level** Large value will be colorful.

**Hue** Change the value by color tuning.

**Brightness** Large value will brighten camera.

**Sharpness** Large value will sharpen camera.

**Contrast** Large value will contrast camera heavily.

Use built-in photo sensor or manual to control ICR.

In case user selects manual mode, there are 4 modes: Night (On), Day (Off), Auto or Schedule to control built-in IR LEDs. This function is very useful under low illumination environment, even at 0 lux.

In case the Auto mode is selected, user needs to specify 3 parameters in advance:

**ICR** **Night Mode Threshold (0~10000):** this value sets the threshold to turn on IR LED. It should be lower or equal to Day Mode Threshold.

**Day Mode Threshold (0~10000):** this value set the threshold to turn off IR LED. It should be higher or equal to Night Mode Threshold.

**Delay Time:** The delay time between LED ON/OFF switching.



The Current Value is the current luminance from the captured video. It's a useful reference to set LED ON/OFF Threshold.

**DIS (Digital)** This function is used to reduce blurring associated with the motion of a camera during exposure. Specifically, it compensates for pan and tilt of a camera. With video cameras, camera shake causes visible frame-to-frame




<b>Image Stabilization</b>	jitter in the recorded video.  Real-time digital image stabilization is used to shift the electronic image from frame to frame of video, enough to counteract the motion. This technique reduces distracting vibrations from videos or improves still image quality by allowing one to increase the exposure time without blurring the image. This technique does not affect the noise level of the image.
<b>2D/3D De-Noise</b>	2D/3D De-Noise can remove or lower unwanted noise and preserve fine details and edges.
<b>Default Settings</b>	Restore to factory image settings.

### 3.6.2 Exposure Control

Picture
Exposure Control
Focus
Privacy Mask
PTZ Setting
Preset Setting
Tour Setting

Power Frequency
50Hz 60Hz
Exposure Control
Auto
Max. Gain
30
Photometry Method
Average
Maximum Exposure Time
1/30 S
Exposure Value
50 (0 ~ 100)
Iris
Enable automatic iris adjustment
WDR
Strength 3



**Power Frequency** Frequency of power line: 50 or 60Hz.

**Auto-Indoor:** It will adjust the image sensor exposure automatically under indoor environment.

**Exposure Control** **Manual Exposure:** User can configure sensor exposure to fixed setting.

**Auto:** It will adjust the image sensor exposure automatically as possible.


**Maximum Exposure Time** Set the Maximum Exposure Time. However, the real exposure time may be shorter if there is a good light condition.

**Exposure Value** Exposure value is AE target value. This value is to adjust the integration, analog gain and digital gain to achieve the target brightness value (Exposure Value).

## WDR

This function is to provide clear images even under back light circumstances. The higher “Strength” level will adjust contrast compensation stronger.

### 3.6.3 Focus



#### Auto Focus

Click this button to activate push AF.

#### Focus

Adjust focus manually.


#### Zoom

Adjust zoom manually.

### 3.6.4 Privacy Mask

Use this page to specify privacy mask window 1 to window 8 and set the name and gray level for selected window.

Picture	Exposure Control	Focus	<b>Privacy Mask</b>	PTZ Setting	Preset Setting	Tour Setting
---------	------------------	-------	---------------------	-------------	----------------	--------------



Name:   
Effect: **Opaque**   
Level: **0 (Black)**   
Cell Size: **8x8**

#### Add and Delete

To add or delete the privacy mask windows, user can specify up to 7 windows to mask the video captured by this device. By dragging mouse on the image, you can change the position and size of the selected window accordingly.

**Name** Name of the specified privacy window

**Effect** There are two types available: Opaque and Mosaic.

**Level** To define the gray level of mask block. The smaller value will be darker.

**Cell Size** To define the cell size of mask block. This option is related to "Mosaic" type.



This function is not recommended for camera with PTZ/ePTZ actions.

### 3.6.5 PTZ Setting

This page allow user to modify the RS-485 interface according to the P/T scanner.

Picture	Exposure Control	Focus	Privacy Mask	<b>PTZ Setting</b>	Preset Setting	Tour Setting
---------	------------------	-------	--------------	--------------------	----------------	--------------

Camera Protocol: **none**


Camera Address: **1**

Baud rate: **9600**

**Camera Protocol** This device can connect to a PTZ camera or speed dome camera and controls them through RS-485 interface.

This is the camera ID set in PTZ camera or speed dome camera.

**Camera Address**



Please DO NOT change the default value if unnecessary. If so, user needs to check and set value properly for both sides.

**Baud Rate**

This is the communication speed between network module and P/T scanner.



If these parameters need to be changed, user needs to check and set value properly for both network module and P/T scanner.

### 3.6.6 Preset Setting

This page provides the edit tool to modify or delete the "Preset Setting" item by item.

Picture	Exposure Control	Focus	Privacy Mask	PTZ Setting	Preset Setting	Tour Setting																
<table border="1"> <thead> <tr> <th>Preset Number</th> <th>Preset Name</th> <th>Home Position</th> </tr> </thead> <tbody> <tr> <td colspan="3" style="height: 100px;"></td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th colspan="2">Preset List</th> </tr> </thead> <tbody> <tr> <td>Preset Number</td> <td><input type="text"/></td> </tr> <tr> <td>Preset Name</td> <td><input type="text"/></td> </tr> <tr> <td>Home Position</td> <td> <input type="radio"/> Enable           <input checked="" type="radio"/> Disable         </td> </tr> <tr> <td colspan="2"> <input type="button" value="Modify"/> <input type="button" value="Delete"/> </td> </tr> </tbody> </table>							Preset Number	Preset Name	Home Position				Preset List		Preset Number	<input type="text"/>	Preset Name	<input type="text"/>	Home Position	<input type="radio"/> Enable <input checked="" type="radio"/> Disable	<input type="button" value="Modify"/> <input type="button" value="Delete"/>	
Preset Number	Preset Name	Home Position																				
Preset List																						
Preset Number	<input type="text"/>																					
Preset Name	<input type="text"/>																					
Home Position	<input type="radio"/> Enable <input checked="" type="radio"/> Disable																					
<input type="button" value="Modify"/> <input type="button" value="Delete"/>																						

### 3.6.7 Tour Setting

Up to 128 positions can be preset, and the camera can be programmed to move to the preset position sequentially.

Picture	Exposure Control	Focus	Privacy Mask	PTZ Setting	Preset Setting	Tour Setting												
<table border="1"> <thead> <tr> <th>Tour Number</th> <th>Tour Name</th> <th>Running</th> </tr> </thead> <tbody> <tr> <td colspan="3" style="height: 150px;"></td> </tr> </tbody> </table>			Tour Number	Tour Name	Running				<table border="1"> <thead> <tr> <th>Sequence</th> <th>Preset Name</th> <th>Wait Time</th> </tr> </thead> <tbody> <tr> <td colspan="3" style="height: 150px;"></td> </tr> </tbody> </table>				Sequence	Preset Name	Wait Time			
Tour Number	Tour Name	Running																
Sequence	Preset Name	Wait Time																
<table border="1"> <tr> <td>Tour Name</td> <td><input type="text"/></td> </tr> <tr> <td>Running</td> <td> <input type="radio"/> Enable           <input checked="" type="radio"/> Disable         </td> </tr> </table>			Tour Name	<input type="text"/>	Running	<input type="radio"/> Enable <input checked="" type="radio"/> Disable	<table border="1"> <tr> <td> <input type="button" value="Add"/> <input type="button" value="Modify"/> <input type="button" value="Delete"/> </td> <td> <input type="button" value="Modify"/> </td> </tr> </table>				<input type="button" value="Add"/> <input type="button" value="Modify"/> <input type="button" value="Delete"/>	<input type="button" value="Modify"/>						
Tour Name	<input type="text"/>																	
Running	<input type="radio"/> Enable <input checked="" type="radio"/> Disable																	
<input type="button" value="Add"/> <input type="button" value="Modify"/> <input type="button" value="Delete"/>	<input type="button" value="Modify"/>																	

**Tour Name**

The group name of the sequence of camera tour. The maximum number of camera tour is 16.

## Running

Enable or disable this camera tour.

## Preset

Set the sequence of the tour. Maximum 16 points can be assigned. The selected preset position is added in the Sequence list from 1 to 16.

## Wait Time

Type a period of time during which the camera is to stay at each preset point, between 0 to 36000 seconds.

### 3.7 System Configuration

Use this menu to perform the principal settings of Internet Camera.

### 3.7.1 System

System	Date & Time	Maintenance
Device Title	<input type="text" value="ICA-4210P"/> (0 ~ 30 Digits)	
Software Version	6.S.0.13541	
Network LED	<input checked="" type="radio"/> Enable <input type="radio"/> Disable	
Power LED	<input checked="" type="radio"/> Enable <input type="radio"/> Disable	
Log	<input type="button" value="Reload"/>	
<pre> Nov  8 20:15:05 168 syslog.info syslogd started: BusyBox v1.18.4 Nov  8 20:15:05 168 syslog.info /etc/rc1.d/S12sysklogd: \$syslogd startup - OK Nov  8 20:15:05 168 user.notice kernel: klogd started: BusyBox v1.18.4 (2014-03-26 1 Nov  8 20:15:05 168 user.info kernel: Initializing cgroup subsys cpuset Nov  8 20:15:05 168 user.info kernel: Initializing cgroup subsys cpu Nov  8 20:15:05 168 user.notice kernel: Linux version 2.6.34.12-WR4.3.0.0_standard-x Nov  8 20:15:05 168 user.warn kernel: CPU: ARMv6-compatible processor [410fb767] rev Nov  8 20:15:05 168 user.warn kernel: CPU: VIPT nonaliasing data cache, VIPT nonalie Nov  8 20:15:05 168 user.warn kernel: Machine: "Xarina" Design Kit from Sony Nov  8 20:15:05 168 user.warn kernel: Memory policy: ECC disabled, Data cache writek Nov  8 20:15:05 168 user.debug kernel: On node 0 totalpages: 32768 Nov  8 20:15:05 168 user.debug kernel: free_area_init_node: node 0, pgdat c067878c, </pre>		

<b>Device Title</b>	You can enter the name of this unit here. It's very useful to identify the specific device from multiple units.
<b>Software version</b>	This information shows the software version in the device.
<b>Network LED</b>	Switch the LED light of this Internet Camera on or off, so that Network LEDs will stop working; in case you don't want other people to know the camera is transferring data.
<b>Power LED</b>	Switch the LED light of this Internet Camera on or off.
<b>Log</b>	User can check the system log information of the device, including the Main Info, Appended Info, Operator IP, and so on.
<b>Reload</b>	Click this button; user can refresh the log information of the device.

### 3.7.2 Date & Time

User can set up the time setting of Internet Camera. Synchronize it with PC or remote NTP server. Also, you may select the correct time zone of your country.



System
Date & Time
Maintenance

Server Date & Time
2012-3-26 12:05:9

PC Time
2012-4-20 15:29:59

Adjust

☒ Synchronize with PC

☐ Manual setting : Date : 2010 May 21 Time : 00 : 00 : 00

☒ Synchronize with NTP

NTP Server
time.stdtime.gov.tw
Test

NTP Sync. Interval
24 hour

Timezone
GMT (Dublin, Lisbon, London, Reykjavik)

Daylight Saving
☒ Disable ☐ Enable

Daylight Saving StartTime
Jan 01 00 : 00 : 00

Daylight Saving StopTime
Jan 01 00 : 00 : 00

Daylight Saving Offset
+ 01 : 00 : 00

<b>Server Date &amp; Time</b>	Displays the date and time of the device	
<b>PC Time</b>	Displays the date and time of the connected PC	
<b>Adjust</b>	<b>Synchronize with PC:</b>	Click this option to enable time synchronization with PC time
	<b>Manual Setting:</b>	Click this option to set time and date manually
	<b>Synchronize with NTP:</b>	Click this option if you want to synchronize the device's date and time with those of time server called NTP server (Network Time Protocol)
<b>NTP Server Name</b>	Type the host name or IP address or domain name of the NTP server.	
<b>NTP Sync. Interval</b>	Select an interval between 1 and 23 hours at which you want to adjust the device's time referring to NTP server	
<b>Time Zone</b>	Set the time difference from Greenwich Mean Time in the area where the device is installed.	
<b>Daylight Saving</b>	Check this item to enable daylight saving adjustment.	
<b>Daylight Saving Start Time</b>	Set up the date and time of daylight saving start time.	
<b>Daylight Saving Stop Time</b>	Set up the date and time of daylight saving stop time.	
<b>Daylight Saving Offset</b>	Set up the date of daylight saving offset.	

### 3.7.3 Maintenance

System
Date & Time
Maintenance

Default Settings (Including Network Setting)	<span style="background-color: white; color: black; padding: 2px 10px;">Factory Default Settings</span>
Default Settings (Excluding Network Setting)	<span style="background-color: white; color: black; padding: 2px 10px;">Default Settings</span>
Backup Setting	<span style="background-color: white; color: black; padding: 2px 10px;">Backup Setting</span>
Restore Setting	<input style="width: 100px;" type="text"/> <span style="background-color: white; color: black; padding: 2px 5px; margin-left: 5px;">Browse...</span> <span style="background-color: white; color: black; padding: 2px 10px; margin-left: 5px;">Restore Setting</span> <span style="background-color: white; color: black; padding: 2px 10px; margin-left: 5px;">Reset</span>
Firmware Upgrade	<input style="width: 100px;" type="text"/> <span style="background-color: white; color: black; padding: 2px 5px; margin-left: 5px;">Browse...</span> <span style="background-color: white; color: black; padding: 2px 10px; margin-left: 5px;">Firmware Upgrade</span> <span style="background-color: white; color: black; padding: 2px 10px; margin-left: 5px;">Reset</span>
System Restart	<span style="background-color: white; color: black; padding: 2px 10px;">Restart</span>

<b>Default Settings (Including the network setting)</b>	Recall the device hard factory default settings. Note that click this button will reset all devices' parameters to the factory settings (including the IP address).
<b>Default Settings (Except the network setting)</b>	The unit is restarted and most current settings are reset to factory default values. This action will not reset the network setting.
<b>Backup Setting</b>	To take a backup of all of the parameters, click this button. If necessary, it will then be possible to return to the previous settings if settings are changed and there is unexpected behavior.
<b>Restore Setting</b>	Click the "Browse" button to locate the saved backup file and then click the "Restore Setting" button. The settings will be restored to the previous configuration.
<b>Firmware Upgrade</b>	<p>The device supports new firmware upgrade.</p> <ol style="list-style-type: none"> <li>1. Close all other application programs which are not necessary for firmware update.</li> <li>2. Make sure that only you access this device at this moment</li> <li>3. Disable Motion Detection function.</li> <li>4. Select "<b>Firmware name</b>"</li> <li>5. Select the Firmware binary file.</li> </ol>
<div style="display: flex; align-items: center;"> <div> <p><b>Note</b></p> <p>Make sure that the Firmware only applies to this device; once updated, it will be burned into FLASH ROM of system.</p> </div> </div>	<ol style="list-style-type: none"> <li>6. Once the firmware file is selected, select "Upgrade".</li> </ol>

7. The upgrade progress information will be displayed on the screen.
8. A message will be shown while the firmware is upgraded. Once the upgrading process is completed, the device will reboot the system automatically.
9. Please wait for 80 seconds, and then you can use PLANET IPWizard II to search the device again.

**Warning!!!** The downloading firmware procedure cannot be interrupted. If the power and/or network connection are broken during the download procedure, it might possibly cause serious damage to the device.

Please be aware that you should not turn off the power during updating the firmware and wait for the “finish” message. Furthermore, do not try to upgrade new firmware if it's not necessary.

**System Restart**

The device is restarted without changing any of the settings.

### 3.8 Video Configuration

This device provides 2 modes of video profile. The first one is 1080P WDR mode which supports video resolution up to 1920x1080 with True WDR function. The second one is 1080P 60FPS mode which supports video resolution up to 1920x1080 at 60fps. User only can select either WDR or 60FPS mode to operate the camera. Switching between WDR and 60fps mode, the device will take time to re-configure system.

### 3.8.1 Common

Common

Overlay Image

Video Profile

ONVIF Profile

AOI

Video Profile

Text Overlay Setting

1080P WDR Mode

1080P WDR Mode

1080P 25FPS WDR Mode

1080P 30FPS Mode

1080P 25FPS Mode

1080P 60FPS Mode

1080P 50FPS Mode

Color

Default Color

Set Color

Default Color

Position

Align Top Left

Include Date

Predefined

YYYY-MM-DD

Own

%Y-%m-%d

(0 ~ 12 Digits)

Include Time

Predefined

24h

Own

%H:%M:%S

(0 ~ 12 Digits)

Include Text

(0 ~ 20 Digits)

#### Video Profile

User can only choose either 1080P or 1080P WDR mode.

#### Text Overlay Setting

There are some important information can be embedded into image, including date, time, and/or text.

### 3.8.2 Overlay Image

User can upload bitmap file to the camera and overlay the picture on streaming video and set its attributes.

Common	Overlay Image	Video Profile	ONVIF Profile	AOI
<div>           Upload Own Image           <input type="checkbox"/> Include overlay image           <div>User Defined Text</div> </div>				
Font Family: <div>Arial</div> Font Size: <div>21</div> Bold: <div>B</div> Italic: <div>I</div> Underline: <div>U</div>				
Font Color: <div>A</div> Background Color: <div>BG</div>				
Text: <div></div>				
<div>Preview</div> <div>Save</div>				
Coordinates <div>X <div>0</div> Y <div>0</div></div>				
File <div>&lt;No overlay image&gt;</div>				
Resolution				
Chroma Key <div>FFFFFF</div> <div>Set Color</div> <div>Default Color</div>				
Transparency <div>0 (opacity)</div>				

<b>Upload Own Image</b>	There are two options: "Image Overlay Setting" or "User Defined Text".
<b>Image Overlay Setting</b>	Check this item to enable image overlay. Otherwise, the uploaded bitmap will not be overlaid on video.
<b>Coordinates</b>	Set position of image on the video.
<b>File</b>	Information of the uploaded bitmap file.
<b>Resolution</b>	Size information of the uploaded bitmap file.
<b>Chroma Key (Background Color)</b>	Define the Chroma key of the uploaded bitmap file. Then user can set transparency of the bitmap.
<b>Transparency</b>	Lower value will lower transparency. Value 0 means opacity.

### 3.8.3 Video Profile

User can modify the detailed parameter for each video profiles on this page.

Common	Overlay Image	Video Profile	ONVIF Profile	AOI																																																																																																			
<table border="1"> <thead> <tr> <th>Name</th> <th>Video Type</th> <th>Resolution</th> <th>Rate Control</th> <th>Quality</th> <th>Bitrate</th> <th>Max Frame Rate</th> <th>GOP Control</th> <th>Multicast</th> </tr> </thead> <tbody> <tr> <td>Profile1</td> <td>h264/Baseline</td> <td>1920x1080</td> <td>EVBR</td> <td>90</td> <td>-</td> <td>30</td> <td>30</td> <td>no</td> </tr> <tr> <td>Profile2</td> <td>h264/Baseline</td> <td>640x480</td> <td>EVBR</td> <td>90</td> <td>-</td> <td>30</td> <td>30</td> <td>no</td> </tr> </tbody> </table>					Name	Video Type	Resolution	Rate Control	Quality	Bitrate	Max Frame Rate	GOP Control	Multicast	Profile1	h264/Baseline	1920x1080	EVBR	90	-	30	30	no	Profile2	h264/Baseline	640x480	EVBR	90	-	30	30	no																																																																								
Name	Video Type	Resolution	Rate Control	Quality	Bitrate	Max Frame Rate	GOP Control	Multicast																																																																																															
Profile1	h264/Baseline	1920x1080	EVBR	90	-	30	30	no																																																																																															
Profile2	h264/Baseline	640x480	EVBR	90	-	30	30	no																																																																																															
<table border="1"> <tbody> <tr> <td>Name</td> <td colspan="8">Profile1</td> </tr> <tr> <td>Video Type</td> <td colspan="8">           h264             Baseline         </td> </tr> <tr> <td>Resolution</td> <td colspan="8">1920x1080</td> </tr> <tr> <td>Rate Control</td> <td colspan="8">           EVBR             Quality 90             Max Bitrate 10000 K bps 1024 ~ 15000         </td> </tr> <tr> <td>Max Frame Rate</td> <td colspan="8">30</td> </tr> <tr> <td>GOP Control</td> <td colspan="8">30</td> </tr> <tr> <td>Multicast</td> <td colspan="8"> <input checked="" type="radio"/> Enable <input type="radio"/> Disable         </td> </tr> <tr> <td>Multicast Video</td> <td colspan="8">           IP Address 239.198.97.181 Port 0 (0 means auto, 1024 ~ 65534)         </td> </tr> <tr> <td>Multicast Audio</td> <td colspan="8">           IP Address 239.198.97.181 Port 0 (0 means auto, 1024 ~ 65534)         </td> </tr> <tr> <td>Time to live</td> <td colspan="8">1 (1 ~ 255)</td> </tr> <tr> <td>Always Enable Multicast</td> <td colspan="8"> <input checked="" type="radio"/> Enable <input type="radio"/> Disable         </td> </tr> </tbody> </table>					Name	Profile1								Video Type	h264 Baseline								Resolution	1920x1080								Rate Control	EVBR Quality 90 Max Bitrate 10000 K bps 1024 ~ 15000								Max Frame Rate	30								GOP Control	30								Multicast	<input checked="" type="radio"/> Enable <input type="radio"/> Disable								Multicast Video	IP Address 239.198.97.181 Port 0 (0 means auto, 1024 ~ 65534)								Multicast Audio	IP Address 239.198.97.181 Port 0 (0 means auto, 1024 ~ 65534)								Time to live	1 (1 ~ 255)								Always Enable Multicast	<input checked="" type="radio"/> Enable <input type="radio"/> Disable							
Name	Profile1																																																																																																						
Video Type	h264 Baseline																																																																																																						
Resolution	1920x1080																																																																																																						
Rate Control	EVBR Quality 90 Max Bitrate 10000 K bps 1024 ~ 15000																																																																																																						
Max Frame Rate	30																																																																																																						
GOP Control	30																																																																																																						
Multicast	<input checked="" type="radio"/> Enable <input type="radio"/> Disable																																																																																																						
Multicast Video	IP Address 239.198.97.181 Port 0 (0 means auto, 1024 ~ 65534)																																																																																																						
Multicast Audio	IP Address 239.198.97.181 Port 0 (0 means auto, 1024 ~ 65534)																																																																																																						
Time to live	1 (1 ~ 255)																																																																																																						
Always Enable Multicast	<input checked="" type="radio"/> Enable <input type="radio"/> Disable																																																																																																						
<p>The High Profile of H.264 codec is automatically changed to Main Profile when the image size is configured as less than 1280x720.</p>																																																																																																							

<b>Name</b>	To assign a name to the selected profile.
-------------	---

<b>Video Type</b>	Video codec of the selected profile.
-------------------	--------------------------------------

<b>Resolution</b>	Resolution of the selected profile.
-------------------	-------------------------------------

Defines the rate control method of this profile. There are three options: Constant Bit Rate (CBR), Variable Bit Rate (VBR), and Enhanced Variable Bit Rate (EVBR).

For CBR, the video bit rate is between low and high bandwidth based on different resolutions. User can set the desired bit rate to match the limitation of bandwidth.

**Rate Control**

For VBR, user should choose the quality level to set the video quality rather than bit rate. The quality level is between 1 and 100. The higher value can reach the better quality but of course will consume higher bandwidth.

For EVBR, the video bitrate is based on normal VBR mode. However, the bitrate can be limited to the max. bitrate while there are lots of motions in video.

<b>Max Frame Rate</b>	Defines the targeted frame rate of this profile. For example, set the frame rate to 15 fps, then the image will be updated for 15 frames per second. User can set the desired max. frame rate versus video quality under the limited bandwidth.
-----------------------	---

<b>GOP Control</b>	Defines the Intra/Inter-frame (I/P) ratio of this profile. For example, set the GOP to 30, then the video stream will have one Intra-frame every 30 frames.
--------------------	---



<b>Multicast</b>	Enable or disable the multicast function.
<b>Multicast Video</b>	IP address and port for multicast video streaming of the selected profile.
<b>Multicast Audio</b>	IP address and port for multicast audio streaming of the selected profile
<b>Time to live</b>	Time to live (TTL) is a mechanism that limits the lifespan of data in a computer or network. Once the prescribed event count or timespan has elapsed, data is discarded. TTL prevents a data packet from circulating indefinitely.
<b>Always Enable Multicast</b>	Multicast streaming is always enabled or by request

### Warning!!!

To enable the multicast streaming, make sure your Intranet does support multicast function. Otherwise, your Intranet may fall into network storm seriously.

## 3.8.4 ONVIF Profile

ONVIF protocol defines profile of video streams. In case, the NVR, CMS and/or VMS connect to this device via ONVIF protocol. Use this page to define parameters of video streams.

Common	Overlay Image	Video Profile	ONVIF Profile	AOI
OnvifProfile1	h264/Baseline	1920x1080	90	10000
OnvifProfile2	h264/Baseline	640x480	90	2000

Name	OnvifProfile1
Video Type	h264 Baseline
Resolution	1920x1080
Rate Control	Quality 90 Max Bitrate 10000 K bps 1024 ~ 15000
Max Frame Rate	30
GOP Control	30
Audio	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Multicast Video	IP Address 239.198.97.181 Port 0 (0 means auto, 1024 ~ 65534)
Multicast Audio	IP Address 239.198.97.181 Port 0 (0 means auto, 1024 ~ 65534)
Time to live	1 (1 ~ 255)

The High Profile of H.264 codec is automatically changed to Main Profile when the image size is configured as less than 1280x720.

<b>Name</b>	To assign a name to the selected profile.
<b>Video Type</b>	Video codec of the selected profile.
<b>Resolution</b>	Resolution of the selected profile.

	<p>Defines the rate control method of this profile. There are three options: Constant Bit Rate (CBR), Variable Bit Rate (VBR), and Enhanced Variable Bit Rate (EVBR).</p> <p>For CBR, the video bit rate is between low and high bandwidth based on different resolutions. User can set the desired bit rate to match the limitation of bandwidth.</p> <p><b>Rate Control</b></p> <p>For VBR, user should choose the quality level to set the video quality rather than bit rate. The quality level is between 1 and 100. The higher value can reach the better quality but of course will consume higher bandwidth.</p> <p>For EVBR, the video bitrate is based on normal VBR mode. However, the bitrate can be limited to the max. bitrate while there are lots of motions in video.</p>
<p><b>Max Frame Rate</b></p>	<p>Defines the targeted frame rate of this profile. For example, set the frame rate to 15 fps, then the image will be updated for 15 frames per second. User can set the desired max frame rate versus video quality under the limited bandwidth.</p>
<p><b>GOP Control</b></p>	<p>Defines the Intra/Inter-frame (I/P) ratio of this profile. For example, set the GOP to 30, then the video stream will have one Intra-frame every 30 frames.</p>
<p><b>Audio</b></p>	<p>Enable or disable the audio function.</p>
<p><b>Multicast Video</b></p>	<p>IP address and port for multicast video streaming of the selected profile.</p>
<p><b>Multicast Audio</b></p>	<p>IP address and port for multicast audio streaming of the selected profile</p>
<p><b>Time to live</b></p>	<p>Time to live (TTL) is a mechanism that limits the lifespan of data in a computer or network. Once the prescribed event count or timespan has elapsed, data is discarded. TTL prevents a data packet from circulating indefinitely.</p>

### Warning!!!

**To enable the multicast streaming, make sure your Intranet does support multicast function. Otherwise, your Intranet may fall into network storm seriously.**

### 3.8.5 AOI

AOI means Area of Interest. Use this page to specify location and size of AOI windows. Only the profiles with H.264 codec and VBR rate control can support AOI function. It enables a non-uniform distribution of the image quality between a selected region (the AOI) and the rest of the image (background).

Common
Overlay Image
Video Profile
ONVIF Profile
**AOI**

Only profile with H.264 codec and VBR rate control supports AOI

#### Add and Del

To add or delete the AOI windows. User can specify up to 2 AOI windows to change the video quality in specified areas. By dragging mouse on the image, you can change the position and size of the selected AOI window accordingly

#### Name

Name of the specified AOI window.

#### Level

Adjust the video quality of specified AOI window. The higher value will be better for video quality.



This function is not recommended for camera with PTZ/ePTZ actions

## 3.9 Audio Configuration

It's M-JPEG mode in this profile.

Setting

Audio

☐ Disable ☒ Enable

Audio Type

g726

Audio Mode

☒ Simplex ☐ Full duplex

Input Gain

80

Output Gain

80

Speaker Out

☐ Disable ☒ Enable

#### Audio

To enable or disable audio function.

#### Audio Type

To select G711 or G726 for *audio* coding.

#### Audio Mode:

To select Simplex or Full duplex (2-way audio) mode.

#### Input Gain:

To adjust gain of input audio.

#### Output Gain:

To adjust gain of output audio.

## 3.10 User Configuration

Use this menu to set the user names and password of the Administrator and up to 10 users, and access right of each user.

Setting

Viewer Login

☒ Anonymous ☐ Only users in database Save

User Name	Access Right	PTZ Control
admin	administrator	yes


User List	
User Name	(1 ~ 20 Digits)
Password	(0 ~ 20 Digits)
Verify Password	(0 ~ 20 Digits)
Access Right	<input type="radio"/> Administrator <input checked="" type="radio"/> Viewer
PTZ Control	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
<span>Add</span> <span>Modify</span> <span>Delete</span>	

<b>Viewer Login</b>	Select "Anonymous" to allow any one viewing the video once connected. Otherwise, only users in database can view the video after login.
<b>Access Right</b>	Administrator can access every function in this device. However, Viewers only can view the video and access limited function.
<b>PTZ Control</b>	Authorize this user to control PTZ function or not.
<b>Add, update, and remove of Users account</b>	Manage the user's account of viewer user.

## 3.11 Protocol Configuration

### 3.11.1 ONVIF

ONVIF is a global and open industry forum with the goal to facilitate the development and use of a global open standard for the interface of physical IP-based security products. In other words, it creates a standard for how IP products within video surveillance and other physical security areas can communicate with each other.



### 3.11.2 SNMP

**Simple Network Management Protocol (SNMP)** is an "Internet-standard protocol for managing devices on IP networks". Devices that typically support SNMP include routers, switches, servers, workstations, printers, and more. It is used mostly in network management systems to monitor network-attached devices for conditions that warrant administrative attention.

SNMP is a component of the Internet Protocol Suite as defined by the Internet Engineering Task Force (IETF). It consists of a set of standards for network management, including an application layer protocol, a database schema, and a set of data objects. SNMP exposes management data in the form of variables on the managed systems, which describe the system configuration. These variables can then be queried (and sometimes set) by managing applications.

ONVIF

SNMP

SNMP v1

☒ Disable
 ☐ Enable

SNMP v2c

☒ Disable
 ☐ Enable

Read community

(< 33 Digits)

Write community

(< 33 Digits)

SNMP version 1 (SNMPv1) is the initial implementation of the SNMP protocol. SNMPv1 operates over protocols such as User Datagram Protocol (UDP), Internet Protocol (IP), OSI Connectionless Network Service (CLNS), AppleTalk Datagram-Delivery Protocol (DDP), and Novell Internet Packet Exchange (IPX). SNMPv1 is widely used and is the de facto network-management protocol in the Internet community

SNMPv2c is defined in RFC 1901–RFC 1908. In its initial stages, this was also informally known as *SNMPv1.5*. SNMPv2c comprises SNMPv2 *without* the controversial new SNMP v2 security model, using instead the simple community-based security scheme of SNMPv1. While officially only a "Draft Standard", this is widely considered the *de facto* SNMPv2 standard.

## 3.12 E-mail Configuration

User may set up SMTP mail parameters for further operation of Event Schedule. If users want to send the alarm message out, it will need to configure parameters here and also add at least one event schedule to enable event triggering.

Setting

SMTP Server

(< 129 Digits)

Test

SMTP Port

(1 ~ 65535)

SSL

☒ Disable
 ☐ Enable

SMTP Authentication

☐ Disable
 ☒ Enable

Authentication User Name

(< 65 Digits)

Authentication Password

(< 22 Digits)

E-mail From

(< 129 Digits)

E-mail To

(< 129 Digits)

E-mail Subject

(< 65 Digits)

### SMTP Server

Type the SMTP server name or the IP address of the SMTP server.

### Test

Send a test mail to mail server to check this account is available or not.



<b>SMTP Port</b>	Set port number of SMTP service.
<b>SSL</b>	Enable SSL function or not.
<b>SMTP Authentication</b>	Select the authentication required when you send an e-mail. <b>Disable:</b> If no authentication is required when an e-mail is send. <b>Enable:</b> If authentication is required when an e-mail is sent.
<b>Authentication User Name</b>	Type the user name for the SMTP server if Authentication is Enabling.
<b>Authentication Password</b>	Type the password for the SMTP server if Authentication is Enabling.
<b>E-mail From</b>	Type the sender's E-mail address. This address is used for reply e-mails.
<b>E-mail To</b>	Type the receiver's e-mail address.
<b>E-mail Subject</b>	Type the subject/title of the e-mail.

## 3.13 Event Detection Configuration

This device supports 5 types of event detection: Object Detection, Camera Tampering, Audio Detection, Face Detection, and Cross Line Detection.

### 3.13.1 Object Detection

Object Detection responds to some kind of object actions in the captured image which will trigger an alarm.

An alarm will be triggered when an object is entering or passing through a specified area or when an object has been left or removed from a guarded area.

Object Detection
Camera Tampering
Audio Detection
Face Detection
Cross Line Detection

1. Motion
Add
Delete

Name  
Motion
Type  
Entrance
Time until theft/desertion object is detected  
10 Seconds
Min. Inspection Trigger Size  
1 X 1
Max. Inspection Trigger Size  
1920 X 1080
Slow Trigger Speed  
1
Fast Trigger Speed  
100
Adjust VMD
Save
Preview Trigger Speed
Stop

<b>Add and Delete</b>	To add or delete the motion windows. User can specify up to 4 included and /or excluded windows to monitor the video captured by this device. By dragging mouse on the image, you can change the position and size of the selected motion window accordingly.
<b>Name</b>	Name of the specified motion window.
<b>Type</b>	Entrance - A moving object exists inside the guarded area. Theft - A static object has been removed from the guarded area. Desertion - A moving object has been left in the guarded area.
<b>Time until theft/desertion object is detected</b>	Specify the reference interval in seconds
<b>Min. Inspection Trigger Size</b>	Specify the minimum trigger size of motion.
<b>Max. Inspection Trigger Size</b>	Specify the maximum trigger size of motion.
<b>Slow Trigger Speed</b>	Specify the minimum speed to be detected.
<b>Fast Trigger Speed</b>	Specify the maximum speed to be detected.
<b>Adjust VMD</b>	Specify the video motion detection details. <b>Enable / Disable:</b> Select the Enable to activate the function to detect object. The dynamic object will be displayed on the monitor in the blue frame. And the static object will be displayed on the monitor in the red frame.

#### Add Detected:

Clicking this button will add an active window on the image screen. User can drag to move the window or resize it.

#### Add Non-Detected:

Clicking this button will add an inactive window on the image screen. User can drag to move the window or resize it.

#### Delete:

Clicking this button will delete a window on the image screen.

#### Name:

Name of the specified VMD window.

#### Sensitivity

Define the sensitivity value of object detection. The higher value will be more sensitivity.

#### Detection Response

Set the response velocity of motion detection.

#### Min. Inspection Trigger Size:


Specify the minimum detection size.

#### Max. Inspection Trigger Size:

Specify the maximum detection size.

#### Moving shadow exemption:

Set ON/OFF for the moving shadow exemption function of object detection. Selecting Do Not Respond to shadows will prevent the shadows of a moving object from being recognized as moving objects.



**This function is not recommended for camera with PTZ/ePTZ actions.**

### 3.13.2 Camera Tampering

Camera tampering detection is a new intelligent functionality that further strengthens the benefit of Network Camera. When the camera is moved, partially obscured, severely defocused, covered or sprayed, an event can be triggered to send notifications, upload images/files to remote server or email.

Object Detection	Camera Tampering	Audio Detection	Face Detection	Cross Line Detection
<div> <div>Camera Tampering</div> <div> <input type="radio"/> Disable           <input checked="" type="radio"/> Enable         </div> </div>				
<div> <div>Defocus Alarm Method</div> <div> <input checked="" type="radio"/> Continue alarm until defocus is corrected.           <input type="radio"/> Stop alarm after <input type="text" value="10"/> Seconds         </div> </div>				
<div> <div>Status</div> <div>Inactive</div> </div>				

#### Audio Alarm Level


Define the threshold value of audio detection.

**Defocus Alarm Method**

Define the minimum triggered duration by camera tampering detection. The triggered duration less than target value will be ignored to filter false alarms.

### 3.13.3 Audio Detection

Audio detection alarm can be used as a complement to motion detection. Since audio detection can react to events in areas too dark for the video motion detection functionality to work properly. In addition, it can be used to detect activity in areas outside of the camera's view.

Object Detection	Camera Tampering	Audio Detection	Face Detection	Cross Line Detection
<div>Audio Detection <input type="radio"/> Disable <input checked="" type="radio"/> Enable</div> <div>Audio Alarm Level <input type="range"/> 6 (0 ~ 100)</div> <div></div>				

**Audio Alarm Level**

Define the threshold value of audio detection.

### 3.13.4 Face Detection

Face detection responds to faces in the camera image and triggers an alarm.

Object Detection
Camera Tampering
Audio Detection
Face Detection
Cross Line Detection



1. DefaultFace
▼

Add
Delete

Name
DefaultFace

☒ Detected
☐ Non-detected

Sensitivity
90 ▼

Min. Detection Size
120 Pixel

Max. Detection Size
960 Pixel

Save

#### Enable / Disable

Select Enable to activate the function to detect human face. The detected faces will be marked by rectangles.

### 3.13.5 Cross Line Detection

Cross Line Detection is a so-called tripwire application. The application detects moving objects that cross a virtual line. Once cross line detected, camera is able to trigger an event automatically.

Cross Line Detection is possible to increase system efficiency by reducing bandwidth and storage needs. The application will work in most indoor and outdoor installations and in variable lighting conditions. It is well suited for many situations, including video monitoring of building entrances, loading docks and parking lots.

Cross Line Detection is an application especially suitable for general entrance and exit detection in low traffic areas. It detects objects such as persons and vehicles that cross a defined virtual line.

Cross Line Detection is easy to configure. A virtual line is positioned in the camera's live view and the detection direction is set. Once placed in the image there is no need for further adjustments.

The real-time visual confirmation validates in an easy way that the application detects objects correctly. Cross Line Detection integrates with the camera's internal event manager enabling various system notifications.



#### Add and Delete

To add or delete the line. User can specify up to 10 cross line to monitor the video captured by this device. By dragging mouse on the image, you can change the position and size of the selected cross line accordingly.

#### Name

Name of the specified cross line detection.

#### Monitoring Direction

The arrow displayed in the center of the line shows the direction of inspection. Trigger is performed when an object passes the line in this direction.

#### Min. Inspection Trigger Size

Specify the minimum trigger size of motion.

#### Max. Inspection Trigger Size

Specify the maximum trigger size of motion.

#### Slow Trigger Speed

Specify the minimum speed to be detected.

#### Fast Trigger Speed

Specify the maximum speed to be detected.

Specify the video motion detection details.

#### Enable / Disable:

Select the Enable to activate the function to detect object. The dynamic object will be displayed on the monitor in the blue frame. And the static object will be displayed on the monitor in the red frame.

#### Adjust VMD

##### Add Detected:

Clicking this button will add an active window on the image screen. User can drag to move the window or resize it.

##### Add Non-Detected:

Clicking this button will add an inactive window on the image screen. User can drag to move the window or resize it.



**Delete:**

Clicking this button will delete a window on the image screen.

**Name:**

Name of the specified VMD window.

**Sensitivity**

Define the sensitivity value of object detection. The higher value will be more sensitivity.

**Detection Response**

Set the response velocity of motion detection.

**Min. Inspection Trigger Size:**

Specify the minimum detection size.

**Max. Inspection Trigger Size:**

Specify the maximum detection size.

**Moving shadow exemption:**

Set ON/OFF for the moving shadow exemption function of object detection. Selecting Do Not Respond to Shadows will prevent the shadows of a moving object from being recognized as moving objects.



**This function is not recommended for camera with PTZ/ePTZ actions.**

## 3.14 Storage Configuration

This page shows the status of the attached SD card and Samba server. You may also set up related parameters to manage the attached SD card or Samba server.

### 3.14.1 SD Card

SD Card

SAMBA Server

Disk ID	SD_DISK		Mount	Unmount
Status	Free space	0% - 0 KB	Reload	Format
	Total size	0 MB		
	Status	No SD card inserted		
	Full	Yes		
	Readonly	No		
<input checked="" type="checkbox"/>	Enable automatic disk cleanup			
	Remove recordings older than:	7	day(s)	
	Remove oldest recordings when disk is:	95	% full	
<input type="checkbox"/>	Lock disk			

<b>Disk ID</b>	This name of SD card.
<b>Status</b>	This information of SD card.
<b>Enable automatic disk cleanup</b>	Delete old recorded files while the conditions are reached as below.
<b>Remove recordings order than</b>	Delete old files by days.
<b>Remove oldest recordings when disk is</b>	Delete old files by left capacity.
<b>Lock disk</b>	Avoid write data and delete at SD card

### 3.14.2 SAMBA Server

SD Card

SAMBA Server

Host	<input type="text"/>	(1 ~ 63 Digits)
Share	<input type="text"/>	(1 ~ 63 Digits)
User Name	<input type="text"/>	(< 64 Digits)
Password	<input type="password"/>	(< 64 Digits)
Status	Not Connect	
Total size	0 KB	
Free space	0% - 0 KB	
SAMBA Server	<input type="button" value="Mount"/>	

<b>Host</b>	Type the server name or the IP address of the SAMBA server.
<b>Share</b>	Set working directory path of SAMBA server.
<b>User Name</b>	Type the user name for the SAMBA server
<b>Password</b>	Type the password for the SAMBA server.

## 3.15 Continuous Recording Configuration

You may enable or disable continuous recording function here. Select Samba server for storage destination.

**Continuous Recording**

Continuous Recording
 ☐ Disable
 ☒ Enable

Record File Type
 


Profile1 h264 / 1600x1200

Disk
 ☒ SD Card
 ☐ SAMBA Server

Path
 

PLANET-00304FA22E92 ( For example: Folder1/Folder2/Folder3 ) (1 ~ 63 Digits)

Restart (Restarting will delete the current recording.)



There are various factors affecting the recording results, such as the camera's system loading, network condition, SD card performance, multiple clients accessing, and so on. No guarantee will be given to "seamless recording" in the recorded video files.

## 3.16 Recording List Configuration

This page only shows the continuous recording files which stored in remote SAMBA server. User may play or delete the selected file

**Continuous Recording List**

Disk: SAMBA Server  
 Path: PLANET-00304FA358EA

Date	File	Trigger by	Size

Reload Recover

Play Remove

## 3.17 Event Server Configuration

### 3.17.1 FTP Server

You may setup FTP parameters for further operation of Event Schedule. If users want to send the alarm message to an FTP server, it will need to configure parameters here and also add at least one event schedule to enable event triggering as SMTP.

FTP Server

TCP Server

HTTP Server

SAMBA Server

Name	FTP Server	FTP Port	FTP Path
FTP	192.168.0.174	21	/anthony/test

Name	FTP	(< 22 Digits)
FTP Server	192.168.0.174	(< 65 Digits) <a href="#">Test</a>
FTP Login Name	admin	(< 22 Digits)
FTP Login Password	*****	(< 22 Digits)
FTP Port	21	(1 ~ 65535)
FTP Path	/admin/test	(< 65 Digits)
FTP Passive Mode	<input checked="" type="radio"/> Disable <input type="radio"/> Enable	

<b>Name</b>	User can specify multiple FTP paths as wish. Therefore, user needs to specify a name for each FTP setting.
<b>FTP Server</b>	Type the server name or the IP address of the FTP server.
<b>Test</b>	Check the FTP server whether this account is available or not.
<b>FTP Login Name</b>	Type the user name for the FTP server.
<b>FTP Login Password</b>	Type the password for the FTP server.
<b>FTP Port</b>	Set port number of FTP service.
<b>FTP Path</b>	Set working directory path of FTP server.
<b>FTP Passive Mode</b>	Select passive or active mode connecting to FTP server.

### 3.17.2 TCP Server

In addition to sending video file to FTP server, the device also can send event message to specified TCP server.

FTP Server
TCP Server
HTTP Server
SAMBA Server

Name	TCP Server	TCP Port
Name	<input type="text" value=""/>	(< 22 Digits)
TCP Server	<input type="text" value=""/>	(< 65 Digits) <span>Test</span>
TCP Port	<input type="text" value=""/>	(1 ~ 65535)

#### Name

User can specify multiple TCP servers as wish. Therefore, user needs to specify a name for each TCP server setting.

#### TCP Server

Type the server name or the IP address of the TCP server.

#### TCP Port

Set port number of TCP server.

### 3.17.3 HTTP Server

The device also can send event message to the specified HTTP server.

FTP Server
TCP Server
HTTP Server
SAMBA Server

Name	HTTP Server	Proxy Address
Name	<input type="text" value=""/>	(< 22 Digits)
URL	<input type="text" value="http://"/>	(< 129 Digits) <span>Test</span>
HTTP Login Name	<input type="text" value=""/>	(< 22 Digits)
HTTP Login Password	<input type="text" value=""/>	(< 22 Digits)
Proxy Address	<input type="text" value=""/>	(< 129 Digits)
Proxy Login Name	<input type="text" value=""/>	(< 22 Digits)
Proxy Login Password	<input type="text" value=""/>	(< 22 Digits)
Proxy Port	<input type="text" value=""/>	(1 ~ 65535)

<b>Name</b>	User can specify multiple HTTP servers as wish. Therefore, user needs to specify a name for each HTTP server setting.
<b>URL</b>	Type the server name or the IP address of the HTTP server.
<b>Test</b>	Check the HTTP server whether it is available or not.
<b>HTTP Login Name</b>	Type the user name for the HTTP server.
<b>HTTP Login Password</b>	Type the password for the HTTP server.
<b>Proxy Address</b>	Type the server name or the IP address of the HTTP Proxy.
<b>Proxy Login Name</b>	Type the user name for the HTTP Proxy.
<b>Proxy Login Password</b>	Type the password for the HTTP Proxy.
<b>Proxy Port</b>	Set port number of Proxy.

### 3.17.4 SAMBA Server

The device also can send video stream to the specified SAMBA server. Most of the times, the SAMBA server will be another PC or NAS server.

FTP Server
TCP Server
HTTP Server
**SAMBA Server**

Name	SAMBA Server	SAMBA Path
samba	192.168.0.201	share

Name	samba	(< 22 Digits)
SAMBA Server	192.168.0.201	(< 65 Digits) <input type="button" value="Test"/>
SAMBA Login Name	test	(< 22 Digits)
SAMBA Login Password	*****	(< 22 Digits)
SAMBA Path	share	(< 65 Digits)

<b>Name</b>	User can specify multiple HTTP servers as wished. Therefore, user needs to specify a name for each HTTP server setting.
<b>SAMBA Server</b>	Type the server name or the IP address of the SAMBA server.
<b>Test</b>	Check the SAMBA server whether this account is available or not.
<b>SAMBA Login name</b>	Type the user name for the SAMBA server.

**SAMBA Login Password** Type the password for the SAMBA server.

**SAMBA Path** Set working directory path of SAMBA server.

## 3.18 Event Schedule Configuration

This menu is used to specify the schedule of Events and activate some actions provided by this device.

### 3.18.1 Setting

Setting		Record	Port Status				
Name	Enable	Type	Weekday	Start	Duration	Trigger by Prefix	Action
Name	<input type="text"/>						
Enable	<input checked="" type="radio"/> Yes <input type="radio"/> No						
Type	<input checked="" type="radio"/> Event Trigger <input type="radio"/> Schedule Trigger, Interval <input type="text" value="60"/> (Seconds)						
Enable Time	<input checked="" type="checkbox"/> Sun <input checked="" type="checkbox"/> Mon <input checked="" type="checkbox"/> Tue <input checked="" type="checkbox"/> Wed <input checked="" type="checkbox"/> Thu <input checked="" type="checkbox"/> Fri <input checked="" type="checkbox"/> Sat Start from <input type="text" value="0"/> : <input type="text" value="0"/> , Duration <input type="text" value="24"/> : <input type="text" value="0"/> ((max 168:00 hours))						
Trigger by	<input type="checkbox"/> Sensor <input type="button" value="Change to active"/> <input type="button" value="v"/> <input type="checkbox"/> Camera Tampering <input type="checkbox"/> Audio Detection <input type="button" value="Over Alarm Level"/> <input type="button" value="v"/> <input type="checkbox"/> Face Detection <input type="checkbox"/> Cross Line Detection <input type="checkbox"/> Object Detection <input type="checkbox"/> Network Disconnect						
Record File Prefix	<input type="text"/> (0 ~ 48 Digits)						

**Name** Name of the Event or Schedule.

**Enable** Enable or disable this Event or Schedule.

**Type** Schedule start with Event trigger or Schedule trigger.

**Enable Time** Define the feasible time slot.

**Trigger by** Select the triggered sources with event trigger.

**Record File Prefix** Define the prefix of recorded filename

**Action** Define the actions once event is triggered.



### Example1.

Setting Record Port Status

Name	Enable	Type	Weekday	Start	Duration	Trigger by Prefix	Action
Send to FTP	yes	Event	1111111	0:0	24:0	x,MD,1	FTP,IR

Name: Send to FTP

Enable: ☒ Yes ☐ No

Type: ☒ Event Trigger ☐ Schedule Trigger, Interval 60 (Seconds)

Enable Time: ☒ Sun ☒ Mon ☒ Tue ☒ Wed ☒ Thu ☒ Fri ☒ Sat  
Start from 0:0, Duration 24:0 ((max 168:00 hours))

Trigger by: ☐ Sensor Change to active ☒ Motion Area DefaultWindow ☒ PIR Change to active

Record File Prefix: (0 ~ 20 Digits)

Action: ☐ Voice Alert, Duration (0~86400 Seconds)  
☐ Alarm Out, Duration (0~86400 Seconds)  
☒ Send FTP FTP  
☐ Send TCP  
☐ Send HTTP  
☐ Send E-Mail  
☒ White-Light LED Night Mode 30 (0~86400 Seconds)  
☐ Send SD

Send file to FTP server by motion triggered always:

1. Select event trigger
2. Enable time: start from 00:00 to 24:00 every day
3. Triggered by: Motion Area (Added to the Object Detection page)
4. Action : Send FTP (Add in Event Server -> FTP Server page)

### Example2.

Setting Record Port Status

Name	Enable	Type	Weekday	Start	Duration	Trigger by Prefix	Action
Send to FTP	yes	Event	1111111	0:0	24:0	x,MD,1	FTP,IR

Name: Send to E-mail

Enable: ☒ Yes ☐ No

Type: ☒ Event Trigger ☐ Schedule Trigger, Interval 60 (Seconds)

Enable Time: ☒ Sun ☒ Mon ☒ Tue ☒ Wed ☒ Thu ☒ Fri ☒ Sat  
Start from 0:0, Duration 24:0 ((max 168:00 hours))

Trigger by: ☐ Sensor Change to active ☒ Motion Area DefaultWindow ☒ PIR Change to active


Record File Prefix: (0 ~ 20 Digits)

Action: ☐ Voice Alert, Duration (0~86400 Seconds)  
☐ Alarm Out, Duration (0~86400 Seconds)  
☐ Send FTP FTP  
☐ Send TCP  
☐ Send HTTP  
☒ Send E-Mail  
To email address support@planet.com.tw  
Subject Motion Detected!

Send file to e-mail server by motion triggered from Friday 18:00 to Saturday 06:00

1. Select event trigger.
2. Enable time: start from Friday 18:00 and keep working for 12 hours, until it stops on Saturday 06:00.
3. Triggered by : Motion Area (Added to Object Detection page)
4. Action : Send e-mail (Add to E-Mail page)
  - i. To email address: You need to input the receiver email address.
  - ii. Subject: You could specify the email subject.
  - iii. Message: You could specify the email content.

### Example3.



The screenshot shows the 'Setting' tab of the web interface. At the top, there are three tabs: 'Setting', 'Record', and 'Port Status'. Below them is a table with the following columns: Name, Enable, Type, Weekday, Start, Duration, Trigger by Prefix, and Action. The table contains one entry: 'Trigger\_Voice\_A...' with 'yes' for Enable, 'Schedule' for Type, '0111110' for Weekday, '18:0' for Start, '12:0' for Duration, 'x,x,x' for Trigger by Prefix, and 'VOICE, IR' for Action.

Below the table is a configuration form for a new trigger. The form has the following fields:

- Name:** Trigger\_Voice\_Aalert
- Enable:** Yes (selected), No
- Type:** Event Trigger (selected), Schedule Trigger, Interval 600 (Seconds)
- Enable Time:** Sun, Mon (selected), Tue, Wed, Thu, Fri, Sat. Start from 18:00, Duration 12:00 (max 168:00 hours).
- Trigger by:** Sensor (selected), Change to active, Motion Area, PIR, Change to active.
- Record File Prefix:** (0 ~ 20 Digits)
- Action:**
  - ☒ Voice Alert, Duration 10 (0~86400 Seconds)
  - ☐ Alarm Out, Duration (0~86400 Seconds)
  - ☐ Send FTP
  - ☐ Send TCP
  - ☐ Send HTTP
  - ☐ Send E-Mail
  - ☒ White-Light LED, Night Mode, 30 (0~86400 Seconds)
  - ☐ Send SD

At the bottom of the form are three buttons: 'Add', 'Modify', and 'Delete'.

Enable Voice Alert every 10 minutes during 18:00 to 24:00 from Monday to Friday.

1. Type: Select schedule trigger and interval is 10 minutes.
2. Enable Time: Select Monday to Friday, and set start time from 18:00 and keep working for in 6 hours.
3. Triggered by: You do not need to choose it, because this will be triggered every minute.
4. Action: Voice Alert.

### 3.18.2 Record

User can choose the type of record file for event or schedule application.

Setting	Record	Port Status
Record File Type	Profile1 h264 / 1920x1080 ▼	
Record File Prefix	<input type="text"/> (0 ~ 20 Digits)	
Pre Trigger Duration	5 (0 ~ 20 Seconds)	
Best Effort Duration	30 (1 ~ 60 Seconds)	
Max File Size	3072 (256 ~ 6144 KB)	

<b>Record File Type</b>	Choose AVI or JPEG file format for record file.
<b>Record File Prefix</b>	Define the prefix of recorded filename.
<b>Pre-Trigger Duration</b>	Define the maximum duration of pre-alarm.
<b>Best Effort Duration</b>	Define the best effort duration of post-alarm.
<b>Max File Size</b>	Define the maximum buffer size of record file.

### 3.18.3 Port Status

User can check the status of digital input and output (DIDO).

Setting	Record	Port Status
Input Status	Input 0: Inactive	
Output Status	Output 0: Inactive	

## Appendix A: Ping IP Address

The PING (stands for Packet Internet Groper) command is used to detect whether a specific IP address is accessible by sending a packet to the specific address and waiting for a reply. It's also a very useful tool to confirm whether Internet Camera is installed or not, or if the IP address conflicts with any other devices over the network.

If you want to make sure the IP address of Internet Camera, utilize the Ping command as follows:

- Start a DOS window.
- Type ping x.x.x.x, where x.x.x.x is the IP address of the Internet Camera.

The replies, as illustrated below, will provide an explanation to the problem.



```
Command Prompt
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

D:\Documents and Settings\Administrator>PING 192.168.0.20

Pinging 192.168.0.20 with 32 bytes of data:

Reply from 192.168.0.20: bytes=32 time<1ms TTL=64
Reply from 192.168.0.20: bytes=32 time<1ms TTL=64
Reply from 192.168.0.20: bytes=32 time<1ms TTL=64
Reply from 192.168.0.20: bytes=32 time<1ms TTL=64

Ping statistics for 192.168.0.20:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 1ms, Average = 0ms

D:\Documents and Settings\Administrator>_
```

If you want to detect any other device conflicting with the IP address of Internet Camera and also can utilize the PING command, you must disconnect the Internet Camera from the network first.

## Appendix B: 3GPP Access

To use the 3GPP function, in addition to previous section, you might need more information or configuration to make this function work.



To use the 3GPP function, it is strongly recommended to install the Networked Device with a public and fixed IP address without any firewall protection.

### **RTSP Port:**

Port 554 is the default for RTSP service. However, sometimes, some service providers change this port number for some reasons. If so, user needs to change this port accordingly.

### **Dialing procedure:**

1. Choose a verified player (PacketVideo or Realplayer currently)
2. Use the following URL to access:

**`rtsp://host/mpeg4/media.3gp`**

Where *host* is the host name or IP address of the camera.

### **Compatible 3G mobile phone:**

Please contact your dealer to get the approved list of compatible 3G phone.




Besides IP camera and 3G mobile phone, you will also need to make sure the ISP and telephone company have provided the 3GPP service to you.

## Appendix C: Bandwidth and Video Size Estimation

The frame rate of video transmitted from the device depends on connection bandwidth between client and server, video resolution, codec type, and quality setting of server. Here is a guideline to help you roughly estimate the bandwidth requirements from your device.

The required bandwidth depends on content of video source. The slow motion video will produce smaller bit rate generally and fast motion will produce higher bit rate vice versa. Actual results generated by the device may be varying.

Image Resolution	Average range of data sizes for JPEG mode	Average bit rate for MPEG4 mode	Average bit rate for H.264 mode
320 x 240	8 ~ 20k byte per frame	256kbps~768kbps @ 30fps	192kbps~512kbps @ 30fps
640 x 480	20 ~ 50K byte per frame	512kbps~3072kbps @ 30fps	384kbps~1536kbps @ 30fps
1920 x 1080	200 ~ 500k byte per frame	-	1536kbps~10000kbps @ 30fps
2048 x 1536	300 ~ 750k byte per frame	-	2048kbps~12000kbps @ 30fps



Note

Audio streaming also takes bandwidth around 32kbps. Some xDSL/Cable modem upload speeds could not even reach up to 128 kbps. Thus, you may not be able to receive good quality video while also streaming audio on a 128 kbps or lower connection. Even though the upload speed is more than 128kbps, for optimal video performance, disabling audio streaming will get better video performance.


## Appendix D: DDNS Application

### 1. Configure PLANET DDNS steps:

**Step 1:** Enable DDNS option through accessing web page of NAS

**Step 2:** Select on DDNS server provide, and register an account if you do not use yet.

Let's take dyndns.org as an example. Register an account in <http://planetddns.com>



The screenshot displays the PLANET DDNS website. The header features the PLANET logo and navigation links for 'PLANET Website', 'FAQ', and 'Support'. The main content area includes a 'Sign in' form with fields for 'ID / Email' and a password, a 'Sign in' button, and links for 'Forgotten Password' and 'Create A New Account'. Below the sign-in section, there are three product highlights: the XRT-401F Internet Broadband Router, the ICA-HM132 2 Mega-Pixel 20M IR Vari-Focal Dome IP Camera, and the ICA-HM316 2 Mega-Pixel 11m Outdoor IR IP Camera, each with a 'More Info' button. At the bottom, there is a section titled 'Access anytime & anywhere' explaining the benefit of DDNS, a 'Support & Download' section with a 'Go!' button, and a footer with links for 'About DDNS' and 'Term of Usage', along with the copyright notice: 'PLANET Technology Corp. Copyright ©2012 All Rights Reserved.'



## Appendix E: Configuring Port Forwarding Manually

The device can be used with a router. If the device wants to be accessed from the WAN, its IP address needs to be setup as fixed IP address, and also the port forwarding or Virtual Server function of router needs to be setup. This device supports UPnP traversal function. Therefore, user could use this feature to configure port forwarding of NAT router first. However, if user needs to configure port forwarding manually, please follow the steps below:

Manually installing the device with a router on your network is an easy 3–step procedure as follows:

1. Assign a local/fixed IP address to your device
2. Access the Router with Your Web browser
3. Open/Configure Virtual Server Ports of Your Router


### 1. Assign a local/fixed IP address to your device

The device must be assigned a local and fixed IP Address that allows it to be recognized by the router. Manually setup the device with a fixed IP address, for example, *192.168.0.100*.

### 2. Access the Router with Your Web browser

The following steps generally apply to any router that you have on your network. PLANET WNRT-620 is used as an example to clarify the configuration process. Configure the initial settings of the router by following the steps outlined in the router's **Quick Installation Guide**.

If you have cable or DSL service, you will most likely have a dynamically assigned WAN IP Address. 'Dynamic' means that your router's WAN IP address can change from time to time depending on your ISP. A dynamic WAN IP Address identifies your router on the public network and allows it to access the Internet. To find out what your router's WAN IP Address is, go to the **Status** screen on your router and locate the WAN information for your router. As shown on the following page the WAN IP Address will be listed. This will be the address that you will need to type in your web browser to view your camera over the Internet. Be sure to uncheck the **Reset IP address at the next boot** button at the top of the screen after modifying the IP address. Failure to do so will reset the IP address when you restart your computer.



Your WAN IP Address will be listed here.


### 3. Open/Set Virtual Server Ports to enable remote image viewing

The firewall security features built into the router and most routers prevent users from accessing the video from the device over the Internet. The router connects to the Internet over a series of numbered ports. The ports normally used by the device are blocked from access over the Internet. Therefore, these ports need to be made accessible over the Internet. This is accomplished using the **Virtual Server** function on the router. The Virtual Server ports used by the camera must be opened through the router for remote access to your camera.

Follow these steps to configure your router's Virtual Server settings


- Click **Enabled**.
- Enter a unique name for each entry.
- Select **Both** under **Protocol Type** (TCP and UDP)
- Enter your camera's local IP Address (e.g., **192.168.0.100**) in the **Private IP** field.
- If you are using the default camera port settings, enter **80** into the **Public** and **Private Port** section, click **Add**.

A check mark appearing before the entry name will indicate that the ports are enabled.



**Note**

Some ISPs block access to port 80. Be sure to check with your ISP so that you can open the appropriate ports accordingly. If your ISP does not pass traffic on port 80, you will need to change the port the camera uses from 80 to something else, such as 8080. Not all routers are the same, so refer to your user manual for specific instructions on how to open ports.



[Home](#) | [General Setup](#) | [Status](#) | [Tool](#)

**Internet Broadband Router**

- System
- WAN
- LAN
- Wireless
- QoS
- NAT
  - ▶ Port Forwarding
  - ▶ **Virtual Server**
  - ▶ Special applications
  - ▶ UPnP Setting
  - ▶ ALG Settings
- Firewall

### Virtual Server ?

You can configure the Broadband router as a Virtual Server so that remote users accessing services such as the Web or FTP at your local site via Public IP Addresses can be automatically redirected to local servers configured with Private IP Addresses. In other words, depending on the requested service (TCP/UDP) port number, the Broadband router redirects the external service request to the appropriate internal server (located at one of your LAN's Private IP Address).

☒ Enable Virtual Server

Private IP	Private Port	Type	Public Port	WAN Port	Comment
<input type="text"/>	<input type="text"/>	<input type="text" value="Both"/>	<input type="text"/>	<input type="text" value="WAN1"/>	<input type="text"/>

Current Virtual Server Tables:

Private IP	Private Port	Type	Public Port	WAN Port	Comment	Select
192.168.0.100	80	TCP+UDP	80	WAN1	ICA+M230	<input type="checkbox"/>

Enter valid ports in the **Virtual Server** section of your router. Please make sure to check the box on this line to enable settings. Then the device can be access from WAN by the router's WAN IP Address.

By now, you have finished your entire PC configuration for this device.

## Appendix F: Power Line Frequency

COUNTRY	VOLTAGE	FREQUENCY	COMMENTS
Argentina	220V	50 Hz	*Neutral and line wires are reversed from that used in Australia and elsewhere.
Australia	230V*	50 Hz	*Outlets typically controlled by adjacent switch. Though <i>nominal</i> voltage has been officially changed to 230V, 240V is within tolerances and commonly found.
Austria	230V	50 Hz	
Brazil	110/220V*	60 Hz	*127V found in states of Bahia, Paraná (including Curitiba), Rio de Janeiro, Paulo and Minas Gerais (though 220V may be found in some hotels). Other areas are 220V only, with the exception of Fortaleza (240V).
Canada	120V	60 Hz	
China	220V	50 Hz	
Finland	230V	50 Hz	
France	230V	50 Hz	
Germany	230V	50 Hz	
Hong Kong	220V*	50 Hz	
India	230V	50 Hz	
Italy	230V	50 Hz	
Japan	100V	50/60 Hz*	*Eastern Japan 50Hz (Tokyo, Kawasaki, Sapporo, Yokohama, and Sendai); Western Japan 60Hz (Osaka, Kyoto, Nagoya, Hiroshima)
Malaysia	240V	50 Hz	
Netherlands	230V	50 Hz	
Portugal	230V	50 Hz	
Spain	230V	50 Hz	
Sweden	230V	50 Hz	
Switzerland	230V	50 Hz	
Taiwan	110V	60 Hz	
Thailand	220V	50 Hz	
United Kingdom	230V*	50 Hz	*Outlets typically controlled by adjacent switch. Though nominal voltage has been officially changed to 230V, 240V is within tolerances and commonly found.
United States of America	120V	60 Hz	

## Appendix G: Troubleshooting & Frequently Asked Questions

Features	
The video and audio codec is adopted in the device.	<p>The device utilizes H.264 and M-JPEG triple compression to provide high quality images. Where H.264 is standards for video compression and M-JPEG is a standard for image compression.</p> <p>The audio codec is defined as AMR for 3GPP and G.711/G.726 for RTSP streaming.</p>
The maximum number of user accesses the device simultaneously.	<p>The maximum number of users is limited to 20. However, it also depends on the total bandwidth accessed to this device from clients. The maximum data throughput of the device is around 20~25Mbps for UDP mode and 10Mbps for HTTP mode. Therefore, the actual number of connected clients is varying by streaming mode, settings of resolution, codec type, frame rate and bandwidth. Obviously, the performance of the each connected client will slow down when many users are logged on.</p>
The device can be used outdoors or not.	<p>The device is not weatherproof. It needs to be equipped with a weatherproof case for outdoor use. However, if equipped with a weatherproof case, the audio function of the device might be disabled.</p>
Install this device	
Status LED does not light up.	<p>Check and confirm that the DC power adaptor, included in packaged, is used. Secure the power connector and re-power it on again.</p>
The network cabling is required for the device.	<p>The device uses Category 5 UTP cable allowing 10 and/ 100 Base-TX/ 1000 Base-T networking.</p>
The device will be installed and work if a firewall exists on the network.	<p>If a firewall exists on the network, port 80 is open for ordinary data communication. The HTTP port and RTSP port need to be opened on the firewall or NAT router.</p>
The username and password for the first time or after factory default reset	<p>Username = <b>admin</b> and password = <b>admin</b>.</p> <p>Note that it's all case sensitivity.</p>
Forgot the username and password	<p>Follow the steps below.</p> <ol style="list-style-type: none"> <li>1. Restore the factory default setting by pressing and holding down for more than 3 seconds on the device.</li> <li>2. Reconfigure the device.</li> </ol>
Forgot the IP address of the device.	<p>Check IP address of device by using the PLANET IPWizard program or by UPnP discovery or set the device to default by Reset button.</p>
PLANET IP Wizard II program cannot find the device.	<ul style="list-style-type: none"> <li>• Re-power the device if you cannot find the unit within 1 minute.</li> <li>• Do not connect device over a router. PLANET IP Wizard II</li> </ul>

	<p>program cannot detect device over a router.</p> <ul style="list-style-type: none"> <li>● If IP address is not assigned to the PC running PLANET IP Wizard II program, then PLANET IP Wizard II program cannot find device. Make sure that IP address is assigned to the PC properly.</li> <li>● Antivirus software on the PC might interfere with the setup program. Disable the firewall of the antivirus software during setting up this device.</li> <li>● Check the firewall setting of your PC or Notebook.</li> </ul>
Internet Explorer does not seem to work well with the device	Make sure that your Internet Explorer is version 6.0 or later. If you are experiencing problems, try upgrading to the latest version of Microsoft's Internet Explorer from the Microsoft webpage.
PLANET IP Wizard II program fails to save the network parameters.	Network may have trouble. Confirm the parameters and connections of the device.
<b>UPnP NAT Traversal</b>	
Cannot work with NAT router	Maybe NAT router does not support UPnP function. Please check user's manual of router and turn on UPnP function.
Some IP cameras are working while others failed	Maybe too many IP cameras have been installed on the LAN, and then NAT router is out of resource to support more cameras. You could turn off and on NAT router to clear out of date information inside router.
<b>Access this device</b>	
Cannot access the login page and other web pages of the Internet Camera from Internet Explorer	<ul style="list-style-type: none"> <li>● Maybe the IP Address of the Internet Camera is already being used by another device or computer. To confirm this possible problem, disconnect the Internet Camera from the network first, and then run the PING utility to check it out.</li> <li>● Maybe due to the network cable. Try correcting your network cable and configuration. Test the network interface by connecting a local computer to the Internet Camera via a crossover cable.</li> <li>● Make sure the Internet connection and setting are ok.</li> </ul> <p>Make sure to enter the IP address of Internet Explorer correctly. If the Internet Camera has a dynamic address, it may have changed since you last checked it.</p> <ul style="list-style-type: none"> <li>● Network congestion may prevent the web page from appearing quickly. Wait for a while.</li> </ul> <p>The IP address and Subnet Mask of the PC and Internet Camera must be in the same class of the private IP address on the LAN.</p> <ul style="list-style-type: none"> <li>● Make sure the http port used by the Internet Camera, default=80, is forwarded to the Internet Camera's private IP address.</li> <li>● The port number assigned in your Internet Camera might not be available via Internet. Check your ISP for available port.</li> <li>● The proxy server may prevent you from connecting directly to the Internet Camera, set up not to use the proxy server.</li> <li>● Confirm that Default Gateway address is correct.</li> <li>● The router needs Port Forwarding feature. Refer to your router's</li> </ul>

	<p>manual for details.</p> <ul style="list-style-type: none"> <li>● Packet Filtering of the router may prohibit access from an external network. Refer to your router's manual for details.</li> <li>● Access the Internet Camera from the Internet with the global IP address of the router and port number of Internet Camera.</li> <li>● Some routers reject the global IP address to access the Internet Camera on the same LAN. Access with the private IP address and correct port number of Internet Camera.</li> <li>● When you use DDNS, you need to set Default Gateway and DNS server address.</li> <li>● If it's not working after the above procedure, reset Internet Camera to default setting and install it again.</li> </ul>
Image or video does not appear on the main page.	<ul style="list-style-type: none"> <li>● The first time the PC connects to Internet Camera, a pop-up Security Warning window will appear to download ActiveX Controls. When using Windows XP, or Vista, log on with an appropriate account that is authorized to install applications.</li> <li>● Network congestion may prevent the Image screen from appearing quickly. You may choose lower resolution to reduce the required bandwidth.</li> </ul>
How to check whether the device's ActiveX is installed on your computer	Go to C:\Windows\Downloaded Program Files and check to see if there is an entry for the file " <b>IPCamera Control</b> ". The status column should show "Installed". If the file is not listed, make sure your Security Settings in Internet Explorer are configured properly and then try reloading the device's home page. Most likely, the ActiveX control did not download and install correctly. Check your Internet Explorer security settings and then close and restart Internet Explorer. Try to browse and log in again.
Internet Explorer displays the following message: "Your current security settings prohibit downloading ActiveX controls".	Setup the IE security settings or configure the individual settings to allow downloading and scripting of ActiveX controls.
The device work locally but not externally.	<ul style="list-style-type: none"> <li>● Might be caused from the firewall protection. Check the Internet firewall with your system or network administrator. The firewall may need to have some settings changed in order for the device to be accessible outside your LAN.</li> <li>● Make sure that the device isn't conflicting with any other web server running on your LAN.</li> <li>● Check the configuration of the router settings allow the device to be accessed outside your local LAN.</li> <li>● Check the bandwidth of Internet connection. If the Internet bandwidth is lower than target bit rate, the video streaming will not work correctly.</li> </ul>
The unreadable characters are displayed.	Use the operating system of the selected language. Set the Encoding or the Character Set of the selected language on the Internet Explorer.
Frame rate is slower than the setting.	<ul style="list-style-type: none"> <li>● The traffic of the network and the object of the image affect the frame rate. The network congestion causes frame rate slower</li> </ul>



	<p>than the setting.</p> <ul style="list-style-type: none"> <li>● Check the bandwidth of Internet connection. If the Internet bandwidth is lower than target bit rate, the video streaming will not work correctly.</li> <li>● Ethernet switching hub can smooth the frame rate.</li> </ul>
Blank screen or very slow video when audio is enabled.	<ul style="list-style-type: none"> <li>● Your connection to the device does not have enough bandwidth to support a higher frame rate for the streamed image size. Try reducing the video streaming size to 160x120 or 320x240 and/or disabling audio.</li> <li>● Audio will consume 32 kbps. Disable audio to improve video. Your Internet connection may not have enough bandwidth to support streaming audio from the device.</li> </ul>
Image Transfer on e-mail or FTP does not work.	<ul style="list-style-type: none"> <li>● Default Gateway and DNS server address should be set up correctly.</li> <li>● If FTP does not work properly, ask your ISP or network administrator about the transferring mode of FTP server.</li> </ul>
Pan/Tilt does not work. (including Click to Center and Preset Positioning)	<ul style="list-style-type: none"> <li>● Click "Refresh" on the Internet Explorer when the communication stops with the device. The image will refresh.</li> <li>● Other clients may be operating Pan/Tilt.</li> <li>● Pan/Tilt operation has reached the end of corner.</li> </ul>
Pan/Tilt does not work smoothly.	<ul style="list-style-type: none"> <li>● There may be a slight delay when you are using the Pan/Tilt feature in conjunction with streaming audio and video. If you find that there is a significant delay while panning or tilting the camera, try disabling the audio streaming and/or reducing the video streaming size.</li> </ul>
<b>Video quality of the device</b>	
The focus on the Camera is bad.	The lens is dirty or dust is attached. Fingerprints, dust, stain, etc. on the lens can degrade the image quality.
The color of the image is poor or strange.	<ul style="list-style-type: none"> <li>● Adjust White Balance.</li> <li>● To ensure the images you are viewing are the best they can be, set the Display property setting (color quality) to 16bit at least and 24 bit or higher if possible within your computer.</li> <li>● The configuration on the device image display is incorrect. You need to adjust the image related parameters such as brightness, contrast, hue and sharpness properly.</li> </ul>
Image flickers.	<ul style="list-style-type: none"> <li>● Wrong power line frequency makes images flicker. Make sure the 50 or 60Hz format of your device.</li> <li>● If the object is dark, the image will flicker. Make the condition around the Camera brighter.</li> </ul>
Noisy images occur.	The video images might be noisy if the device is located in a very low light environment. Make the condition around the camera brighter or turn the White-light LED on.
<b>Miscellaneous</b>	

Cannot play the recorded ASF file

Please install Microsoft®'s DirectX 9.0 or later and uses the Windows Media Player 11.0 or later to play the AVI filed recorded by the device.